

Operator's Manual

Vector™ Multi-Cook Oven

VMC-F3E VMC-F4E



Structured Air Technology™

MN-39279-EN

REV.01 1/18

EN





Manufacturer's Information

Copyright © Copyright 1/18 by Alto-Shaam, Inc.

All rights reserved.

This manual or any portion thereof may not be reproduced or used in any manner whatsoever without the express written permission of Alto-Shaam, Inc.

Trademarks All trademarks referenced in this documentation are the property of their

respective owners.

Manufacturer Alto-Shaam, Inc.

P.O. Box 450

W164 N9221 Water Street Menomonee Falls, WI 53052

Original instructions The content in this manual is written in American English.

FOREWORD

Enjoy your Alto-Shaam Vector Oven!

Structured Air Technology™ The Alto-Shaam Vector Oven features Structured Air Technology, giving you two, three or four ovens in one. It gives you the flexibility to simultaneously cook a variety of menu items with no flavor transfer. It provides the ability to control temperature, fan speed, and time in each individual oven chamber.

Cook up to twice the food than a traditional convection oven, with no microwaves, and no water.

Extend Your Manufacturer's Warranty

Register

Register your Alto-Shaam appliance online, and you will automatically be entered into a monthly drawing to win an additional year extended warranty! Registering your appliance ensures prompt service in the event of a warranty claim. You will also receive direct notifications of software updates and additional product information.

Your personal information will not be shared with any other company.

www.alto-shaam.com/warranty

Alto-Shaam 24/7 Emergency Repair Service

Call 800-558-8744 to reach our 24-hour emergency service call center for

immediate access to local authorized service agencies outside standard business hours. The emergency service access is provided exclusively for Alto-Shaam equipment and is available throughout the United States through Alto-Shaam's

toll free number.

Availability Emergency service access is available seven days a week, including holidays.



FOREWORD



Manufacturer's Information	. 2
Foreword Enjoy your Alto-Shaam Vector Oven!	. 3
Table of Contents	5
Safety The Meaning of Signal Words	. 8
Labels Label Locations	13 . 13
Installation Dimensions Drawing	. 20 . 21 . 22
How to Turn On and Turn Off the Oven How to Set Preheat Temperatures How to Preheat the Oven. How to Cook in Manual Mode. How to Use the Dual Timers. How to Cook with Programmed Recipes. How to Cook With Linked Chambers. How to Cook Using Combined Chambers. How to Cook Using a Probe. How to Create and Edit Recipes. How to Create and Edit Recipes. How to Create and Edit Recipe Folders. How to Save Recipes to a USB Drive. How to Turn On and Turn Off the Chambers. How to Enable Manual Mode, Linking, and Set Temp Function. How to Change the Time and Date Settings.	. 35 . 38 . 41 . 44 . 51 . 54 . 57 . 60 . 62 . 64 . 67 . 70
How to Change the Time and Date Settings	. 77 . 78
DOW TO SELLIE CLEARING TIMEL	. ŏl



TABLE OF CONTENTS

How to Adjust the Oven Light Duration	83
How to View the Oven Logs	84
Maintenance	87
How to Clean the Oven	87
Troubleshooting	91
What to do if the Fan Indicator Light Illuminates	91
What to do if the High Limit Screen Displays	92
Warranty	93
Warranty	93



The Meaning of Signal Words

Technical content produced by Alto-Shaam contains signal words where needed. These signal words must be obeyed to reduce the risk of death, personal injury, or equipment damage. The meaning of these signal words is explained below.



DANGER

Danger indicates a hazardous situation, which if not avoided, will result in serious injury or death.



WARNING

Warning indicates a hazardous situation, which if not avoided, could result in serious injury or death.



CAUTION

Caution indicates a hazardous situation, which if not avoided, could result in minor or moderate injury.

NOTICE

Notice indicates a situation, which if not avoided, could result in property damage.



NOTE: Note indicates additional information that is important to a concept or procedure.







Appliance Description and Intended Use

Structured Air Technology™

Alto-Shaam Vector's Structured Air Technology system allows for multiple, unique cooking chambers within the same oven. Air is delivered by a blower located in the rear of each cooking chamber. Air travels vertically through the jet plates into each chamber. The food product is blown with hot air from above and below. Structured Air plates at the top and bottom of the oven complete the upper and lower cooking chambers. Each cooking chamber is independent from the other and includes its own blower and heat source. The operator can select the optimal cooking temperature, air velocity, and cook time for each chamber either manually or through programmed recipes.





Configurations

The Vector F Series is available in two configurations: three-, and four-chamber. On F4 series ovens, the upper two chambers may be combined into one large chamber, and the lower two chambers may be combined into one large chamber. On F3 series ovens, the lower two chambers may be combined into one large chamber.

Intended use

The Vector series ovens are intended to cook and warm food only. Any other use is prohibited.

Residual risks

This oven is manufactured using ISO-certified processes. The oven is designed with maximum safety in mind; however, there are residual risks to operators of this oven. Residual risks include exposure to heat and exposure to hot food products.

Possible misuse

Misuse of this oven includes loading the oven with anything other than a food product. Misuse also includes heating or cooking any food product that contains alcohol or other flammable substance.



Safety Precautions

Before you begin

Read and understand all instructions in this manual.

Electrical precautions

Obey these precautions while using the appliance:

- Connect the appliance to a properly grounded outlet. Do not use the appliance if it is not properly grounded. Consult an electrician if there is any doubt that the outlet used is properly grounded.
- Keep the cord away from hot surfaces.
- Do not attempt to service the appliance or its cord and plug.
- Do not operate the appliance if it has a damaged cord or plug.
- Do not immerse the cord or plug in water.
- Do not let the cord hang over the edge of a table or counter.
- Do not use an extension cord.

Usage precautions

Obey these precautions when using the appliance:

- Only use this appliance for its intended use of heating or cooking.
- Use utensils and protective clothing such as dry oven mitts when loading and unloading the appliance.
- Use caution when using the appliance. Floors adjacent to the appliance may become slippery.
- Do not cover or block any of the openings of this appliance.
- Do not cover racks or any other part of this appliance with metal foil.
- Do not use this appliance near water such as a sink, in a wet location, near a swimming pool, or similar locations.
- Do not unplug or disconnect the appliance immediately after cooking. The cooling fans must stay on to protect electrical components.

Maintenance precautions

Obey these precautions when cleaning and maintaining the appliance:

- Obey precautions in the manual, on tags, and on labels attached to or shipped with the appliance.
- Only clean the appliance when the main disconnect switch is in the OFF position.
- Do not store the appliance outdoors.
- Do not clean the appliance with metal scouring pads.
- Do not use corrosive chemicals when cleaning the appliance.
- Do not use a hose or water jet to clean the appliance.
- Do not use the appliance cavity for storage.
- Do not leave flammable materials, cooking utensils, or food inside the appliance when it is not in use.
- Do not remove the top cover or side panels. There are no user-serviceable components inside.



Operator training

Before using the appliance:

- Read and understand the operating instructions contained in all the documentation delivered with the appliance.
- Know the location and proper use of all controls.
- Keep this manual and all supplied instructions, diagrams, schematics, parts lists, notices, and labels with the appliance if the appliance is sold or moved to another location.
- Contact Alto-Shaam for additional training if needed.

Operator qualifications

Only trained personnel are permitted to use the appliance. They must meet the following qualifications:

- Have received proper instruction on how to use the appliance
- Are familiar with commercial kitchens and commercial appliances

The appliance must not be used by:

- Persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision concerning use of the appliance by person responsible for their safety.
- People impaired by drugs or alcohol.
- Children should be supervised to ensure that they do not play with the appliance.
- Children shall neither clean nor maintain the appliance.

Condition of appliance

Only use the appliance when:

- All controls operate correctly
- The appliance is installed correctly
- The appliance is clean
- The appliance labels are legible

Servicing the appliance

- Only trained personnel are permitted to service or repair the appliance. Repairs that are not performed by an authorized service partner or trained technician, or the use of non-factory parts, will void the warranty and relieve Alto-Shaam of all liability.
- To prevent serious injury, death or property damage, have the appliance inspected and serviced at least every twelve (12) months by an authorized service partner or trained technician.
- Contact Alto-Shaam for the authorized service partner in your area.

Sound power

The A-weighted sound pressure level is below 70 dB(A).



Personal Protective Equipment (PPE)

Wear the following Personal Protective Equipment (PPE) while cleaning the appliance.


- Protective gloves
- Protective clothing
- Eye protection
- Face protection






ABELS

Label Locations





Made in U.S.A. DE IN U.S. Pull the knob out when cooking with combined chambers. Push the knob in when cooking with all chambers. 2 LA-39431 WARNING Hot surface 3 WARNING **M** WARNING/ADVERTENCIA/AVERTISSEMENT Electric Shock Hazard
To reduce the risk of electric shock, do not remove or open cover. No user-serviceable parts inside.
Refer servicing to qualified personnel.
Qualified personnel: Disconnect power before servicing. Electric shock hazard To reduce the risk of electric shock, do not remove Qualitied personnei: Disconnect power before servicing.

Peligro de descarga eléctrica
Para reducir el riesgo de descarga eléctrica, no retire ni
abra la cubierta. No hay piezas en el interior a la que se
les pueda realizar mantenimiento. Derive el mantenimiento
a personal calificado.
Personal calificado: Desconecte la energia antes de
realizar mantenimiento. or open the cover. No user-serviceable parts inside. Refer servicing to qualified personnel. Qualified personnel: Disconnect power before servicing. reanizar mantenimiento.

Danger de décharge électrique

Pour réduire le risque de décharge électrique, ne par
ouvrir ni retirer le capot. Ne contient pas de pièces
réparables par l'utilisateur. Confier les réparations à du
personnel qualifié :
Personnel qualifié : Sectionnez l'alimentation avant
toute intervention.

LA-38! 3



Check fans Check fans Compruebe los ventiladores Vérifiez les ventilateurs 4 LA-39280 WARNING ⚠ WARNING / ADVERTENCIA / AVERTISSEMENT Burn hazard. Always load liquids, or foods that can become liquid when heated, at an eye level where they can be seen. Burn hazard Peligro de quemaduras. Siempre coloque líquidos, o alimentos que se puedan volver líquidos cuando se calientan, a nível de los ojos donde se puedan ver. Always load liquids, or foods that can become liquid when heated, at an eye level where they can be Risque de brûlure. Toujours charger les liquides, ou les aliments qui deviennent liquides au chauffage, à hauteur des yeux où ils peuvent être vus. seen. 5 WARNING ↑ WARNING/ADVERTENCIA/AVERTISSEMENT Fire Hazard Fire hazard For use only on noncombustible surfaces. Maintain the correct clearances to combustibles Peligro de incendio Solo para uso en superficies no combustibles Mantenga las distancias correctas de elemen For use only on noncombustible surfaces. Maintain the correct clearances to combustibles. Risque d'incendie Combustibles | Non-combustibles 2" (51mm) Top/tope/haut 2" (51mm) Left/izquierda/gauche 2" (51mm) 2" (51mm) Right/derecho/droite 2" (51mm) 2" (51mm) Rear/posterior/arrière 2" (51mm) 6 Security seal ESCHINI ESBIJIN ESBI^N ESCHINI ESBI^N ESCHINI ESBI^N ESCHINI ESBI^N 7

WARNING ↑ WARNING/ADVERTENCIA/AVERTISSEMENT This oven is only for use with factory-supplied legs, casters, or base. Fire hazard This oven is only for use with factory-supplied legs, 8 Peligro de incendio Este horno solo se puede usar con patas, ruedas o base proporcionadas por la fábrica. casters, or base. Risque d'incendie Ce four est destiné à être utilisé uniquement avec les pieds, les roulettes ou le socle fournis par le fabricant. WARNING MARNING/ADVERTENCIA/AVERTISSEMENT Electric Shock Hazard
To reduce the risk of electric shock, do not remove or open cover. No user-serviceable parts inside.
Refer servicing to qualified personnel.
Qualified personnel: Disconnect power before servicing. Electric shock hazard To reduce the risk of electric shock, do not remove Peligro de descarga eléctrica.

Para reducir el riesgo de descarga eléctrica, no retire ni abra la cubierta. No hay piezas en el interior a la que se les pueda realizar mantenimiento. Derive el mantenimiento a personal calificado.

Personal calificado: Desconecte la energía antes de realizar mantenimiento. or open the cover. No user-serviceable parts inside. 9 Refer servicing to qualified personnel. Qualified personnel: Disconnect power before servicing. Danger de décharge électrique
Pour réduire le risque de décharge électrique, ne par
ouvrir ni retirer le capot. Ne contient pas de pièces
réparables par jutilisaleur. Confier les réparations à du personnel qualifié.
Personnel qualifié : Sectionnez l'alimentation avant toute intervention **Note:** This label is only used on UL-certified appliances AWG for supply connections. that have 120V to ground wiring. Use only copper wires suitable for temperatures \geq 90°C. Do not connect to a circuit operating at more than 150 VAC to ground.


For use on individual branch circuits only. AWG 90°C Use _____ AWG for supply connections. Use AWG _____ para las conexiones de suministro.
Use solo cables de cobre aptos para temperaturas mayores que 90 °C. Use only copper wires suitable for temperature less 10 No conecte a un circuito que funcione a más de 150 V CA a tierra. than or equal to 90°C. Para su uso en circuitos derivados individuales solamente Utiliser du calibre ___ Do not connect to a circuit operating at more than Utiliser exclusivement des conducteurs en cuivre qui conviennent à des températures $\geq 90~^\circ\text{C}.$ 150 VAC to ground. Ne pas raccorder à un circuit fonctionnant sous plus de 150 VCA par rapport à la terre. Utiliser exclusivement sur des circuits de dérivation propres LA-38852 For use on individual branch circuits only. Every Alto-Shaam product is precision calibrated prior to release from the factory to ensure accurate ALTO-SHAAM temperature control. Every Alto-Shaam product is precision calibrated 11 prior to release from the factory to ensure accurate temperature control. CALIBRATION TECHNICIAN_ LA-26378 Line 1 supply terminal 12 I A-36443-I 1 Line 2 supply terminal 13 LA-36443-L2



14	L3 LA-36443-L3	Line 3 supply terminal
15	LA-36443-N	Neutral
16	LA-36443-G	Ground terminal
17	LA-36443-E	Equipotential terminal



Dimensions Drawing





How to Receive the Appliance

Responsible parties

When an Alto-Shaam preferred carrier is used, shipping damage is a matter between Alto-Shaam and the carrier. In such cases, contact Alto-Shaam customer service.

When an Alto-Shaam non-preferred carrier is used, shipping damage is a matter between the carrier and the consignee. In such cases, the carrier is assumed to be responsible for the safe delivery of the merchandise, unless negligence can be established on part of the shipper.

Receive the oven

When receiving the appliance, do the following.

Step	Action
1.	Inspect the equipment while it is still in the truck or immediately after it is moved to the receiving area. Do not wait until after the equipment is moved to a storage area.
2.	Inspect and count all merchandise received. Do not sign a delivery receipt or a freight bill until you have done so.
3.	Note all damage to packaging and to the equipment on the carrier's receipt.
4.	Request the driver sign the delivery receipt. If the driver refuses to sign, make a note of this refusal on the delivery receipt.
5.	Write the following on the delivery receipt if the driver refuses to allow an inspection: Driver refuses to allow inspection of containers for visible damage.
6.	Contact the carrier immediately upon finding damage, and request an inspection. Follow the carrier's policies and procedures.

Alto-Shaam policy

It is the policy of Alto-Shaam to assist customers in collecting claims that have been properly filed and actively pursued. Alto-Shaam cannot, however, file damage claims, assume the responsibilities for damage claims, or accept deductions in payment for damage claims.



How to Unpack the Oven

Before you begin

Make sure you have:

- An appropriate lifting device, and enough personnel, to safely move and position the weight of the oven.
 - VMC-F3E: 472 lb (214 kg)VMC-F4E: 599 lb (272 kg)
- Cutting tools to remove the packaging

Unpack the oven

To unpack the oven, do the following.

Step Action

1. **Remove** the box. **Save** all packing materials for inspection by the carrier.



NOTE: Examine the appliance for damage. If the appliance has been damaged, do not use the appliance until it has been inspected by an authorized service provider. Contact your carrier or Alto-Shaam customer service.

- 2. **Remove** the shrink wrap.
- 3. **Cut** the plastic straps.
- 4. **Remove** the foam from each chamber.
- 5. **Remove** the oven from the pallet.

Result

The oven is now unpacked.



How to Install the Oven (60 Hz Models Without Cords or Plugs)

Before you begin

Make sure you have:

- Appropriate cord and plug. See local codes and regulations.
- Screwdriver (Phillips #2)
- Nut driver (1/4-inch)
- An appropriate lifting device, and enough personnel, to safely move and position the weight of the oven.

VMC-F3E: 472 lb (214 kg)VMC-F4E: 599 (272 kg)

Requirements

- The oven must be installed on a level surface.
- The oven must not be installed in any area where it may be affected by steam, grease, dripping water, high temperature, or any other severely adverse conditions.
- The oven is not intended for built-in installation.

Voltages

	V	Ph	Hz	A	Breaker*	kW
VMC-F3E	208-240 380-415	3 3	60 60	31-35 32-35	50 50	11.2 - 14.5 12.2 - 14.5
VMC-F4E	208-240 380-415	3	60 60	41-46 42-46	60 60	14.8 - 19.2 16.2 - 19.8

^{*}Electrical connections must meet all applicable federal, state, and local codes.




Position the oven

To position the oven, do the following.

Step Action

- 1. **Make sure** that:
 - The location where the oven is being installed is rated to support the weight of the oven,
 - The oven is within five feet of the appropriate electrical outlet,
 - You follow the oven clearance guidelines.




2. **Move** the oven to the installation location and onto the final resting surface.

The oven is now correctly positioned.

Level the oven

To level the oven, do the following.

3. **Check** the level of the oven using a spirit (bubble) level. Check front to back and side to side.




Adjust the legs, if necessary, to achieve levelness.


The oven is now level.

Connect the wiring


To connect the wiring, do the following.




7. **Remove** the 2 screws from the bracket **4**).



8. **Remove** the 2 screws from the bracket **(5)**.




9. **Install** the cord **(6)** through the cord grip **(7)**. **Install** the cord and cord grip into the oven.





10. **Install** the lock nut onto the cord grip.


Connect the supply cord to the appropriate terminals (L1, L2, L3, etc.) in accordance with local codes and regulations.



Install the ground wire to the ground terminal **8**.

Leave an extra loop 9 so that current-carrying conductors become taut before the ground wire if the cord is accidentally pulled. Follow applicable regulations.

Tighten the cord grip sealing nut onto the supply cord.



- **(i)**
- **NOTE:** The equipotential-bonding terminal is located at the bottom rear of the oven.
- 11. **Re-install** the 2 screws to the bracket.
- 12. **Re-install** the bracket.
- 13. **Connect** the fan motor wire connector.
- 14. **Re-install** the side panel.
- 15. **Re-install** the back panel.

Result

The oven is now installed.



How to Install the Oven (50 Hz Models Without Cords or Plugs)

Before you begin

Make sure you have:

- Appropriate cord and plug, minimum oil resistant HO7RN-F. See local codes and regulations.
- Screwdriver (Phillips #2)
- Nut driver (1/4-inch)
- An appropriate lifting device, and enough personnel, to safely move and position the weight of the oven.
 - □ VMC-F3E: (214 kg)
 - □ VMC-F4E: (272 kg)

Requirements

- The oven must be installed on a level surface.
- The oven must not be installed in any area where it may be affected by steam, grease, dripping water, high temperature, or any other severely adverse conditions.
- If required by local codes, use Type F RCD.
- The oven is not intended for built-in installation.

Voltages

	v	Ph	Hz	A	Breaker*	kW	Wire Size (mm²)**
VMC-F3E	380-415	3	50	32-35	50	12.2 - 14.5	4
VMC-F4E	380-415	3	50	42-46	60	16.2 - 19.2	10

^{*}Electrical connections must meet all applicable codes.



^{**}IEC 60335 minimum.

INSTALLATION

Wire sizes

60335-1 IEC:2010


Rated current of appliance A	Nominal cross-sectional area mm ²
>0.2 - ≤3	0.5
>3 - ≤0	0.75
>6 - ≤10	1.0
>10 - ≤16	1.5
>16 - ≤25	2.5
>25 - ≤32	4
>32 - ≤40	6
>40 - ≤63	10

Position the oven

To position the oven, do the following.

Step Action

- 1. **Make sure** that:
 - The location where the oven is being installed is rated to support the weight of the oven,
 - The oven is within five feet of the appropriate electrical outlet,
 - You follow the oven clearance guidelines.




2. **Move** the oven to the installation location and onto the final resting surface.

The oven is now correctly positioned.



Level the oven


To level the oven, do the following.



The oven is now level.


Connect the wiring

To connect the wiring, do the following.







5. **Disconnect** the fan motor wire connector **2**.




6. **Remove** the back panel ③.




7. **Remove** the 2 screws 4 from the bracket.



8. **Remove** the 2 screws **(5)** from the bracket.




9. **Install** the cord **(6)** through the cord grip **(7)**. **Install** the cord and cord grip into the oven.



10. **Install** the lock nut onto the cord grip.

Connect the supply cord to the appropriate terminals (L1, L2, L3, etc.) in accordance with local codes and regulations.



Install the ground wire to the ground terminal 8.


Leave an extra loop **9** so that current-carrying conductors become taut before the ground wire if the cord is accidentally pulled. Follow applicable regulations.

Tighten the cord grip sealing nut onto the supply cord.



INSTALLATION

Continued from previous page





NOTE: The equipotential-bonding terminal is located at the bottom rear of the oven.

- 11. **Re-install** the 2 screws to the bracket.
- 12. **Re-install** the bracket.
- 13. **Connect** the fan motor wire connector.
- 14. **Re-install** the side panel.
- 15. **Re-install** the back panel.

Result

The oven is now installed.

OPERATION


How to Turn On and Turn Off the Oven

Before you begin

The oven must be connected to electric power.

Turning on the oven

To turn on the oven, do the following.



The oven is now on.



OPERATION

Continued from previous page

Turning off the oven

To turn off the oven, do the following.

2. **Press and hold** the ON/OFF button ② until the LED above the ON/OFF button illuminates red.

The oven activates the blowers for the cool down process. The screen displays a cool down prompt and asks for the door to be opened. The oven deactivates the blowers when the cool down process is complete.



The oven is now off.




How to Set Preheat Temperatures

Before you begin

- The oven must be turned on (screen is on).
- Factory preset preheat temperature for each chamber is 350°F (177°C).


Procedure

To set the preheat temperatures, do the following.







3. **Touch** the Temps icon (3). The Set Preheat Temperatures screen displays.



4. **Touch** the chamber **(4)**. The existing temperature displays. **Enter** the cooking temperature using the number pad. **Touch** the green check mark.



5. **Repeat** the process for the other chambers if desired.






6. **Touch** the green check mark **⑤**.



7. **Touch** the up arrow **(6)** then the back arrow **(7)** to return to the home screen.



Result

The preheat temperatures have now been set.




How to Preheat the Oven

Before you begin

- The oven must be connected to electric power.
- The oven chambers should be empty.

All chambers simultaneously

To preheat all chambers simultaneously, do the following.





Individual chambers separately

To preheat individual chambers separately, continue.

2. **Touch** the chamber icon ②. The check mark signifies the chosen chamber.




NOTE: The Set Temp function must be enabled. See topic How to Enable Manual Mode, Linking, and Set Temp Function.

Touch the Set Temp icon (3). The Enter Temperature screen displays.

Enter the temperature (4) using the number pad.

Touch the green check mark **(5)**. The oven starts the preheat process.



Screen loading bars

On the left side of the screen, red screen loading bars indicate each chamber's progress towards reaching its set temperature.



The screen displays the chamber's actual temperature and its set temperature. Selecting different chambers displays information on their respective temperatures.

Touch the cancel icon **(6)** to cancel the preheating process before the individual chamber reaches its preset preheat temperature. Each chamber must be canceled individually.



OPERATION

Length of time to preheat

It takes approximately 10-15 minutes (dependent upon the set temperature) for the oven to reach temperature.

As each chamber reaches its set temperature, it starts a countdown from 5 minutes to let the temperature stabilize. After that, the screen displays READY to indicate that the chamber is ready for cooking.



Result

The oven is now ready for cooking.

How to Cook in Manual Mode

Step

Action

Before you begin


- Be sure the oven is warmed up. Refer to topic How to Preheat the Oven.
- The Manual function must be enabled. See topic How to Enable Manual Mode, Linking, and Set Temp Function.
- Be sure your food is prepared and ready to cook.

Procedure

To cook in manual mode, do the following.


Touch the chamber ①. The check mark signifies the chosen chamber. 1. **Touch** Manual (2). The manual mode screen displays. 555 <u>{{}</u> 9 Ready Ready 00:00 Ready 00:00 Ready Ready 450°F Ready Ready Air Speed ∇ VMC-TS-003241

2. **Touch** the time setting ③. **Enter** the cooking time using the number pad. **Touch** the green check mark.






3. **Touch** the temperature setting **4**). **Enter** the cooking temperature using the number pad. **Touch** the green check mark.



- **NOTE:** If entering a cooking temperature that differs from the preheat temperature, let the oven adjust to the cooking temperature before loading the oven.
- 4. **Touch** Air Speed **⑤**. **Enter** the air flow in percentage 10%–100% using the number pad. **Touch** the green check mark.
 - **NOTE:** The Air Speed icon will flash until a value is entered. You must enter values for time, temperature, and air speed.



5. **Load** the food into the oven.



6. **Touch** the green start icon **(6)**. The timer starts counting. **Pressing** the X icon **(7)** stops the timer. The timer resets to 0.









NOTE: Cooking time and air speed may be adjusted any time during the cooking cycle. The timer stops when the door is open, and resumes when the door is closed.

At the end of the cooking process, the oven sounds an alert and the chamber light flashes. The DONE screen displays.

7. **Open** the door and remove the hot food.

Result

The food is now cooked.

How to Use the Dual Timers

Before you begin


Refer to topic How to Cook in Manual Mode

Background


There may be times when you will want to use the same chamber to cook two pans of food at the same time, but at different intervals. The dual timer function allows you to do so.

Procedure

To cook using the dual timers, do the following.




2. **Touch** the time setting ③. **Enter** the cooking time using the number pad. **Touch** the green check mark.






3. **Enter** the time **4** for the second pan of food.



4. **Touch** the temperature setting **⑤**. **Enter** the cooking temperature using the number pad. **Touch** the green check mark.






NOTE: If entering a cooking temperature that differs from the preheat temperature, let the oven adjust to the cooking temperature before loading the oven.



5. **Touch** Air Speed **6**. **Enter** the air flow in percentage 10–100% using the number pad. **Touch** the green check mark.



NOTE: The Air Speed icon will flash until a value is entered. You must enter values for time, temperature, and air speed.



6. **Open** the door and load pan 1. **Close** the door.

Touch the green start icon (7). The timer for pan 1 will start counting.



7. **Open** the door and load pan 2 when it is ready. **Close** the door. **Touch** the green start icon (8). The timer for pan 2 will start counting

Touch the green start icon **(8)**. The timer for pan 2 will start counting. **Pressing** the X icon **(9)** stops the timer. The timer resets to 0.





At the end of the cooking process, the oven sounds an alert and the chamber light flashes. The DONE screen displays.

8. **Open** the door and remove the hot food.

Result

The food is now cooked.

How to Cook with Programmed Recipes

Before you begin

- Be sure the oven is preheated
- Be sure your food is prepared and ready to cook

Procedure

To cook using a programed recipe, do the following.

Step Action

1. **Select** the chamber ①. The check mark indicates the chosen chamber. **Touch** Program ②.



2. **Navigate** to the recipe using the arrows ③. Recipes are sorted first by set temperature and then alphabetically.





NOTE: If the recipe is highlighted in red, it means that the item cannot be cooked at the chamber's current set temperature. Selecting a recipe highlighted in red will start a preheat or cool-down cycle to adjust the temperature to that of the selected recipe.



- Open the door and load the food into the selected chamber.
 Close the door.
- 4. **Touch** the recipe **4**). The oven starts cooking.

During the cooking process

The screen indicates the time remaining.



- The menu area displays details on the current cook setting.
- Touching the cancel icon stops the cooking process.
- Opening the door (to load another chamber or check on a cooking process) pauses the cooking process. The oven will keep track of how long the door is open and automatically add the time to any current cooking process to compensate for the temperature loss.



Switch to another chamber to cook another product.



OPERATION

Continued from previous page

Result

At the end of the cooking process, the oven sounds an alert and the chamber light flashes. The DONE screen displays.



How to Cook with Linked Chambers

Before you begin

- The selected chambers must be warmed up to the temperature of the recipe. Refer to topic How to Preheat the Oven.
- The Link function must be enabled. See topic How to Enable Manual Mode, Linking, and Set Temp Function.
- The oven must be in Program mode.

Linking chambers

To link chambers, do the following.

1. Touch the Program icon ①. | Ready | Ready





3. Touch the chambers ③ you want to link.

Touch the green check mark ④.

NOTE: Pressing All On selects all chambers.
Chambers with a ∞ icon are linked

Result

The chambers are now linked.

Cooking with linked chambers

To cook with linked chambers, do the following.

4. **Navigate** to the recipe using the arrow icons **(5)**.





Ready

Open the door and load the selected chambers. **Touch** the recipe **(6)**. The Cooking screen displays and the cooking process 6. starts. **(**) <u>∭</u> Preheat <u>\$\$\$</u> • ω**√** 8 Cooking Ready 00] [Program 3:00 Ready Ready 350°F Program Biscuits Ready 300°F Program Rea

350°F

Result

At the end of the cooking process, the oven sounds an alert and the chamber light flashes. The DONE screen displays.

Ready 225°F Program




How to Cook Using Combined Chambers


Before you begin

Be sure your food is prepared and ready to cook

Procedure

To cook using combined chambers, do the following.








3. **Preheat** the oven.



4. **Select** the chamber ③. The check mark indicates the chosen chamber. **Navigate** to the recipe using the arrows ④. Recipes are sorted first by set temperature and then alphabetically.





- Open the door and load the food into the selected chamber.Close the door.
- 6. **Touch** the recipe **(5)**. The oven starts cooking.




During the cooking process

The screen indicates the time remaining.



- The menu area displays details on the current cook setting.
- Touching the cancel icon stops the cooking process.
- Opening the door (to load another chamber or check on a cooking process) pauses the cooking process. The oven will keep track of how long the door is open and automatically add the time to any current cooking process to compensate for the temperature loss.





Result

At the end of the cooking process, the oven sounds an alert and the chamber light flashes. The DONE screen displays.


How to Cook Using a Probe

Before you begin

Be sure your food is prepared and ready to cook

Procedure

To cook using a probe, do the following.





Select the chamber (3). The check mark indicates the chosen chamber. **Navigate** to the recipe using the arrows (4). Recipes are sorted first by set temperature and then alphabetically.



NOTE: If the recipe is highlighted in red, it means that the item cannot be cooked at the chamber's current set temperature. Selecting a recipe highlighted in red will start a preheat or cool-down cycle to adjust the temperature to that of the selected recipe.

- 5. **Open** the door and load the food into the selected chamber.
- 6. **Insert** the probe into the food.

Close the door.

Touch START (5). The oven starts cooking.






During the probe cooking process

The screen indicates the elapsed time of the probe cook. When the internal food temperature is reached, the probe cook is complete. The recipe continues to cook any additional stages.



- The menu area displays details on the current cook setting.
- Touching the cancel icon stops the cooking process.





Result

At the end of the cooking process, the oven sounds an alert and the chamber light flashes. The DONE screen displays.




How to Create and Edit Recipes

Before you begin

You will need to know the pass code. The pass code set at the factory is 12345.

Procedure


To create or edit a recipe, do the following.



2. **Touch** the Recipes icon ②. The Enter Pass Code screen displays.

Enter the pass code 12345 3.

Touch the green check mark **(4)**. The Recipes screen displays.



From the Recipes screen you can browse existing recipes or create a new recipe. Touching an existing recipe allows you to edit it. Touching the new recipe icon (5) creates a new recipe.



- 3. **Touching** the new recipe icon or touching an existing recipe allows access to the following:
 - Recipe name
 - Temperature for each stage
 - Time for each stage
 - Air speed for each stage
 - Number of stages (By default, stages 2 and 3 have a length of zero.)



Touching the cancel icon **(6)** discards any changes.

Touching the delete icon \bigcirc deletes the recipe.

4. **Touch** the green check mark icon (8) when finished to save the recipe.

Result

This ends the procedure.




How to Create and Edit Recipe Folders

Before you begin

You will need to know the pass code. The pass code set at the factory is 12345.

Procedure


To create or edit a recipe folder, do the following.



2. **Touch** the Recipes icon ②. The Enter Pass Code screen displays.

Enter the pass code 12345 3.

Touch the green check mark **4**. The Recipes screen displays.



From the Recipes screen you can browse existing recipe folders or create a new recipe folder. Touching an existing recipe folder allows you to edit it. Touching the new folder icon (5) creates a new folder.



3. **Create** a new folder or **edit** an existing folder.

Touch the recipes you want to add to the folder.





Touching the cancel icon **6** discards any changes.

Touching the delete icon \bigcirc deletes the folder.

4. **Touch** the green check mark icon **(8)** when finished to save the folder.

Result

This ends the procedure.


How to Load Recipes from a USB Drive

Before you begin

- You will need a USB drive loaded with recipes.
- You will need to know the pass code. The pass code set at the factory is 12345.

Procedure

To load recipes from the USB drive, do the following.






3. **Plug** the USB drive into the port ③.




4. **Touch** Load Recipes **4**). The Enter Pass Code screen displays.

Enter the pass code 12345 (5).

Touch the green check mark **6**.



5. **Touch** the recipe file **7**.





OPERATION

Continued from previous page

Loading/reading the recipes

The oven loads the selected config file (recipe). The Loading Config File screen displays.



The oven turns off after the recipes are loaded.

Result

The recipes are now loaded.


How to Save Recipes to a USB Drive

Before you begin

- You will need a USB drive.
- You will need to know the pass code. The pass code set at the factory is 12345.

Procedure

To download recipes from the oven to a USB drive, do the following.







3. **Plug** the USB drive into the port ③.



4. **Touch** Save Recipes **4**). The Enter Pass Code screen displays. **Enter** the pass code 12345 **5**). **Touch** the green check mark **6**).



The oven downloads the recipes onto the USB drive. The default name for the file generated is ui_dump.ai2. If another file with the same name is present, the oven will add numbers after the name so that no file is overwritten: ui_dump1.ai2, ui_dump2.ai2, ui_dump3.ai2 and so on.



The Saving Recipes screen displays during the saving process. When the process is complete, the USB Functions screen displays.



5. **Touch** the cancel icon **(7)** then the back arrow **(8)** to return to the home screen.



6. **Remove** the USB drive.

Result

The recipes are now saved to the USB drive.




How to Turn On and Turn Off the Chambers

Before you begin

The oven must be connected to electric power.

Turning off a chamber

To turn off a chamber, do the following.



2. **Repeat** the process for other chambers.

The chamber is now off.



Turning on a chamber

To turn on a chamber, do the following.

Touch the Set Temp icon ②. The check mark signifies the chosen chamber.

Touch the Set Temp icon ③. The Enter Temperature screen displays.

Enter the temperature ④ using the number pad.

Touch the green check mark ⑤. The chamber turns on.

Enter Temperature (*F)

Ready to Preheat

OFF

Ready to Preheat

Cookins

Ready

Prior Cookins

Ready

Program

Ready

Re

The chamber is now on.




How to Enable Manual Mode, Linking, and Set Temp Function

Before you begin


The oven must be turned on (screen is on).

Procedure

To enable the Set Temp, Linking, or Manual mode, do the following.




3. **Touch** the down arrow **③**. The third User Configuration screen displays.




4. **Touch** the function you want to enable: Set Temp, Link, or Manual icon **4**. The Enter Pass Code screen displays.

Enter the pass code 12345 **⑤**. The selected function will now be enabled.

Repeat the process to disable the function.








Result

Set Temp, Linking, or Manual mode is now enabled.

How to Change the Time and Date Settings

Procedure

To change the time and date settings, do the following.





3. Touch the green check mark ③ when finished.

Touch the back arrow ④ to return to the home screen.

Edit Date and Time

User Configuration

Sounds

XX = XX = XXXX

15: 17

Logs
Recipes

VMC-TS-003368

Result


The time and date have been changed.



How to Change the Sound Settings

Procedure

To change the sound settings, do the following.



Result


The sound settings have been changed.




How to Change the Temperature Scale

Procedure

To change the temperature scale from °F to °C and vice versa, do the following.





Result

The temperature scale has now been changed.




How to Set the Cleaning Timer

Before you begin

To help you remember when to clean the oven, the number of hours until the next cleaning may be programmed into the controller.


Procedure

To set the cleaning timer, do the following.




3. **Touch** the Clean icon ③. The Enter Pass Code screen displays. **Enter** the pass code 12345 ④.

Touch the green check mark **(5)**.




4. **Enter** the operating hours **(6)** until the oven needs to be cleaned.

Touch the green check mark **7**.







The cleaning timer is now set.

To view the cleaning hours

During the start-up process:

■ The screen indicates the number of hours until cleaning is needed.



How to Adjust the Oven Light Duration

Before you begin

The oven must be turned on (screen is on).

Procedure


To adjust the oven light duration, do the following.

Step Action

1. **Touch and hold** the oven light icon ①. The Enter Pass Code screen displays.

Enter the pass code 12345 2.


Touch the green check mark (3).



2. **Enter** the number of minutes **4** the oven light will stay on.

Touch the green check mark **(5)**.

NOTE: Entering zero minutes results in the oven light staying on indefinitely.



Result

The oven light duration has now been set.




How to View the Oven Logs

Before you begin


The oven must be turned on (screen is on).

Procedure


To view the oven logs, do the following.



Touch Press here to see log details 3. The logs display.
 Touch the up and down arrows 4 to scroll through the logs.



4. **Touch** the back arrow **(5)** then the back arrow **(6)** to return to the User Configuration screen.





OPERATION

Continued from previous page

5. **Touch** the back arrow **(7)** to return to the home screen.



Result

The oven logs have now been viewed.

How to Clean the Oven

Before you begin



WARNING: Electric shock hazard.

Set the main disconnect switch to the OFF position to remove electric power from the appliance.



CAUTION: Burn hazard.

Allow the oven, utensils, and racks to cool before cleaning.



CAUTION: Corrosive materials hazard.

Wear eye protection and hand protection when cleaning.

NOTICE

Using improper cleaning procedures could damage the catalyst and void the warranty.

Only use spray cleaner when the electric power is completely removed from the oven.

Do not spray the catalyst with water or cleaning solution.

Do not spray cleaner into the oven while the recirculation blower is running.

Do not use steel pads, wire brushes, or scrapers when cleaning.

Make sure that the oven is turned off and cool—chambers are less than $140^{\circ}F$ (60°C).

Daily cleaning procedure

To clean the oven daily, do the following.

Step	Action
1.	Remove any spills with disposable paper wipes or a damp cloth.
2.	Wipe the outside of the oven with a damp cloth.
3.	Wipe the outside of the oven with a stainless steel cleaner.




Weekly cleaning procedure

To clean the oven weekly, do the following.

Action Step

Set the main disconnect switch (1) to the OFF position. 1.

Make sure the oven is cool—chambers are less than 140°F (60°C).



2. **Spray** the exterior areas of the oven with EcoLab Greaselift™ or Chemco Dirt Buster III™ oven cleaner.

NOTICE Use only non-caustic cleaners.

Do not spray directly into the fan openings on the rear of the oven.

Do not use cleaners that contain sodium hydroxide (lye) or phosphorus.

- 3. **Wipe** the exterior areas of the oven with a non-abrasive nylon scrub pad.
- 4. **Clean** each side of the window pane with EcoLab Greaselift™ or Chemco Dirt Buster III™ oven cleaner.
- **Set** the main disconnect switch (1) to the ON position when complete. 5.



Monthly cleaning procedure

To clean the oven monthly, do the following.

Step Action

1. **Set** the main disconnect switch to the OFF position.


Make sure the oven is cool—chambers are less than 140°F (60°C).

Remove the cooking racks (1) and jet plates (2).



CAUTION: Personal injury hazard.

Use hand protection when handling the jet plates.



2. **Separate** the jet plates.

> Spray the jet plates with EcoLab Greaselift™ or Chemco Dirt Buster III™ (3) oven cleaner. Let the cleaner work for 3–5 minutes.



- 3. **Wipe** the jet plates with a non-abrasive nylon scrub pad.
- **Spray** the inside walls of the oven with EcoLab Greaselift™ or Chemco Dirt 4. Buster III™ oven cleaner. Let the cleaner work for 3–5 minutes.
- 5. **Wipe** the inside walls of the oven with a non-abrasive nylon scrub pad.
- 6. **Re-install** the jet plates and cooking racks.




NOTE: Make sure the jet plates are installed correctly. The nozzles on the jet plates should be pointing towards the food.



Cleaning the filters

7. **Remove** the filters **4**.



8. **Clean** the filters in a dishwasher.



NOTE: Replace the filters at least once a year.

- 9. **Re-install** the filters.
- 10. **Set** the main disconnect switch to the ON position when complete.

Result

The oven is now clean.

What to do if the Fan Indicator Light Illuminates

Procedure

If the fan indicator light (1) illuminates, do the following.


Step **Action** 1. Turn off the oven and allow it to cool. **Remove** the filters (2). অঅ ৰ ৰ ৰ w w w w ব্য ব্য w w <u>~</u>~ ক্র ক্র VMC-TS-003153 2. Clean the filters in a dishwasher. **Re-install** the filters. 3. 4. **Resume** operation of the oven. **NOTE:** If the fan indicator light remains on, the appliance is malfunctioning. Disconnect the appliance from the power supply and have the oven serviced by a qualified technician.



What to do if the High Limit Screen Displays

Procedure

If the high limit screen displays ①, do the following.



WARRANTY

Warranty

Introduction

Alto-Shaam, Inc. warrants to the original purchaser only, that any original part found to be defective in material or workmanship will be replaced with a new or rebuilt part at Alto-Shaam's option, subject to provisions hereinafter stated.

Warranty Period

The original parts warranty period is as follows:

- For all other original parts, one (1) year from the date of installation of appliance or fifteen (15) months from the shipping date, whichever occurs first.
- The labor warranty period is one (1) year from the date of installation or fifteen (15) months from the shipping date, whichever occurs first.
- Alto-Shaam will bear normal labor charges performed during standard business hours, excluding overtime, holiday rates or any additional fees.
- For the refrigeration compressor, if installed, the warranty period is five (5) years from the date of original installation of the appliance.
- For heating elements on Halo Heat® Cook and Hold ovens, the warranty period is for as long as the original owner owns the oven. This warranty period applies to units sold after 2/1/2009 and excludes holding-only ovens.
- To be valid, a warranty claim must be asserted during the applicable warranty period. This warranty is not transferable.

Exclusions

This warranty does not apply to:

- Calibration.
- Replacement of light bulbs, rubber gaskets, grease filters, air filters, racks, jet plates, and/or the replacement of glass due to damage of any kind.
- Equipment damage caused by accident, shipping, improper installation or alteration.
- Equipment used under conditions of abuse, misuse, carelessness or abnormal conditions, including but not limited to, equipment subjected to harsh or inappropriate chemicals, including but not limited to, compounds containing chloride or quaternary salts, poor water quality, or equipment with missing or altered serial numbers.
- Equipment damage caused by use of any cleaning agents other than those recommended by Alto-Shaam, including but not limited to damage due to chlorine or other harmful chemicals.
- Any losses or damage resulting from malfunction, including loss of food product, revenue, or consequential or incidental damages of any kind.
- Equipment modified in any manner from original model, substitution of parts other than factory authorized parts, unauthorized removal of any parts including legs, or unauthorized addition of any parts.





- Equipment damage incurred as a direct result of poor water quality*, inadequate maintenance of steam generators and/or surfaces affected by water. Water quality and required maintenance of steam generating equipment is the responsibility of the owner/operator.
- Equipment damage incurred as a result of not following the required maintenance schedule published in the manuals for the equipment.

Conclusion

This warranty is exclusive and is in lieu of all other warranties, express or implied, including the implied warranties of merchantability and fitness for a particular purpose. No person except an officer of Alto-Shaam, Inc. is authorized to modify this warranty or to incur on behalf of Alto-Shaam any other obligation or liability in connection with Alto-Shaam equipment.

*Refer to the product spec sheet for water quality standards.





Alto-Shaam World Headquarters

W164 N9221 Water Street, P.O. Box 450 Menomonee Falls, WI 53052-0450, U.S.A. Phone 800-558-8744; +1-262-251-3800

Alto-Shaam Asia

Shanghai, China Phone +86-21-6173 0336

Alto-Shaam Canada

Concord, Ontario Canada Toll Free Phone 866-577-4484 Phone +1-905-660-6781

Alto-Shaam Central & South America

Miami, FL USA Phone +1-954-655-5727

Alto-Shaam Middle East & Africa

Phone +971 4 321 9712

Alto-Shaam France, L.L.C.

Aix en Provence, France Phone +33(0)4-88-78-21-73

Alto-Shaam GmbH

Bochum, Germany Phone +49(0)234-298798-0

Alto-Shaam Mexico

Leon, Mexico Phone +52 1 477-754-1305

Alto-Shaam Russia

Moscow, Russia Phone +7-903-793-2331