



[www.CarnivalKingSupplies.com](http://www.CarnivalKingSupplies.com)

# USER MANUAL



## COTTON CANDY MACHINE

Item # 382CCME21 & 382CCM28



05/2019



# COTTON CANDY MACHINE MANUAL

## General Safety Precautions

1. This manual will outline safety warnings and precautions, operating, maintenance and cleaning. The warnings and instructions reviewed in this manual cannot cover all possible conditions and situations that may occur. Factors such as caution and common sense cannot be built into this product and it is trusted the operator will follow these measures.
2. This machine must never be modified and should only be used for its intended purpose.
3. Always check that the cotton candy machine is plugged into a grounded outlet with the appropriate electrical supply. Ensure that the wall outlet being used is properly grounded. If it is not, you must install a grounded outlet. Have the work performed only by a certified electrician who is properly qualified to meet local safety and electrical codes.
4. Before disconnecting from the power source, be sure that all switches have been turned OFF. To unplug the machine, firmly grasp the plug and remove from the outlet – never pull on the cord itself.
5. Ensure that the power outlet, plug and cord being used are in good, working condition. Damaged components should be repaired by a certified electrician who is qualified to meet local safety and electrical codes. Even with a properly functioning power cord, keep water away from the cord and avoid letting your power cord run over carpets or heating devices.
6. If missing or broken components are found, leave the machine TURNED OFF. Do not attempt to use it. Contact a qualified service technician to make all repairs.
7. No one under 18 should operate this machine unsupervised.
8. Keep hands, foreign objects, and loose clothing away from the spinning head while in use.
9. Always use the machine in a clean and dry area.

## Operating Instructions

1. Install the bowl on top of the base using the 4 clamps located on the sides of the base. Make sure the bowl is not in contact with the heating head. Place floss bubble shield (optional) on top of the bowl.
2. Connect the power cord to the base and plug it into a grounded outlet.
3. Switch both the “power” and “heat” switches to the ON position. Both switches will light up when turned on.
4. Allow the machine 15-20 minutes to heat prior to use.
5. Add floss sugar directly into the well in the heating head using the floss scoop. Do not overfill.
6. Cotton candy will begin to spin around the bowl as the heater head continues to operate. As the cotton candy accumulates, it will build up and come out through the top of the spinner head. You will need to collect the cotton candy as it comes out of the top of the unit.
7. Allow the machine to cool down for 15-20 minutes after an hour of continuous use.

### Cotton Candy Machine Specs

Item#	382CCME21
Base Dimensions	12.5" x 12.5" x 12.5"
Bowl Dimensions	21" Diameter
Voltage	110V
Wattage	1030W
Yield	2 Cones/90 Seconds

### Cotton Candy Machine Specs

Item#	382CCM28
Base Dimensions	12.5" x 12.5" x 12.5"
Bowl Dimensions	28" Diameter
Voltage	110V
Wattage	1030W
Yield	2 Cones/Minute



# COTTON CANDY MACHINE MANUAL

## Cleaning and Maintenance

1. After use be sure to turn off and unplug the machine.
2. Allow all components to cool off to a temperature that is safe to touch.
3. Wipe down the spinning head with water, a mild soap such as 147SUNBRIGHT and a non-abrasive towel. Then wipe with clear water. Dry Completely.
4. Remove the four screws from the top of the spinning head and remove the bowl which holds the floss sugar.
5. Wires are now exposed. Cover the opening with a towel to prevent any outside contaminants.
6. It may be necessary after heavy use to first soak the bowl in hot water and mild soap prior to step 7.
7. Wipe down the bowl with water, a mild soap such as 147SUNBRIGHT and a non-abrasive towel. Rinse. Dry Completely.
8. After all parts are completely dry, reassemble the machine.

## Parts and Accessories

### 382CCME21

Part Name	Replacement Part Item #
Floss Bowl Stabilizer Net and Clips	382CCMNET
Floss Bubble	382FB21
Belt	382CCMBELT
Carbon Brush	382CCM28BRSH
Motor	382CCM28MTR
Copper Floss Band	382CCM28RING
Hi-Limit Thermostat	382CCM28TL
Heating Head	382CCMHH
Fuse	382CCM28FUSE

### 382CCM28

Part Name	Replacement Part Item #
Floss Bowl Stabilizer Net and Clips	382CCMNET
Floss Bubble	382FB28
Belt	382CCMBELT
Carbon Brush	382CCM28BRSH
Motor	382CCM28MTR
Copper Floss Band	382CCM28RING
Hi-Limit Thermostat	382CCM28TL
Heating Head	382CCMHH
Fuse	382CCM28FUSE

## Also available...

### Floss Bubble Shield (sold separately)

#382FB21 (21") & #382FB28 (28")

Floss bubbles help protect against airborne debris. Simply set on top of your 21" or 28" Carnival King Cotton Candy Machine and begin serving up delicious cones of cotton candy to your customers!





# COTTON CANDY MACHINE MANUAL

## Equipment Limited Warranty

Carnival King warrants its equipment to be free from defects in material and workmanship for a period of 90 days. This is the sole and exclusive warranty made by Carnival King covering your Carnival King brand equipment. A claim under this warranty must be made within **90 days** from the **date of purchase** of the equipment. Only the equipment's original purchaser may make a claim under this warranty. Carnival King reserves the right to approve or deny the repair or replacement of any part or repair request. The warranty is not transferable. Carnival King Equipment installed in/on a food truck or trailer will be limited to a period of **30 days** from the original date of purchase.

### To Make a Warranty Claim:

For Warranty Inquiries contact the location where you purchased the product:

- **WebstaurantStore.com:** Contact [help@webstaurantstore.com](mailto:help@webstaurantstore.com). Please have your order number ready.
- **The Restaurant Store:** If you purchased this unit from your local store, please contact your store directly.
- **TheRestaurantStore.com:** Online purchases, call 717-392-7261. Please have your order number ready.

Failure to contact the designated location prior to obtaining equipment service may void your warranty.

Carnival King makes no other warranties, express or implied, statutory or otherwise, and **HEREBY DISCLAIMS ALL IMPLIED WARRANTIES, INCLUDING THE IMPLIED WARRANTIES OF MERCHANTABILITY AND OF FITNESS FOR A PARTICULAR PURPOSE.**

### This Limited Warranty does not cover:

- Equipment sold or used outside the Continental United States
- Carnival King has the sole discretion on wearable parts not covered under warranty
- Equipment not purchased directly from an authorized dealer
- Equipment that has been altered, modified, or repaired by anyone other than an authorized service agency
- Equipment where the serial number plate has been removed or altered.
- Damage or failure due to improper installation, improper utility connection or supply, and issues resulting from improper ventilation or airflow.
- Defects and damage due to improper maintenance, wear and tear, misuse, abuse, vandalism, or Act of God.

Any action for breach of this warranty must be commenced within 90 days of the date on which the breach occurred. No modification of this warranty, or waiver of its terms, shall be effective unless approved in a writing signed by the parties. The laws of the Commonwealth of Pennsylvania shall govern this warranty and the parties' rights and duties under it. Carnival King shall not under any circumstances be liable for incidental or consequential damages of any kind, including but not limited to loss of profits.