


AP 550

LABEL APPLICATOR



Operator's Guide

PRIMERA

© 2013 All rights reserved.

For the most recent version of this manual please visit
www.primeralabel.com

Notices: The information in this document is subject to change without notice. NO WARRANTY OF ANY KIND IS MADE WITH REGARD TO THIS MATERIAL, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. No liability is assumed for errors contained herein or for incidental or consequential damages in connection with the furnishing, performance, or use of this material. This document contains proprietary information that is protected by copyright. All rights are reserved. No part of this document may be photocopied, reproduced, or translated into another language without prior written consent.

Trademark Acknowledgments: Primera is a registered trademark of Primera Technology Inc. Windows is a registered trademark of Microsoft Corporation. All other trademarks are the property of their respective owners.

Printing History

Edition 1.2, 052615, Copyright 2013, All rights reserved.

FCC Compliance Statement: This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

For Users in the United States: This product is intended to be supplied by a UL listed Direct Plug-In Power Supply marked "Class 2" or a UL listed ITE Power Supply marked "LPS" with output rated 12v, 5 amps or higher. This equipment has been tested and found to comply with the limits for a "Class B" digital device, pursuant to Part 15 of the FCC Rules. In a domestic environment this product may cause radio interference, in which case the user may be required to take adequate measures. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Re-orient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Use of shielded cables is required to comply with the "Class B" limits of Part 15 of the FCC Rules. You are cautioned that any changes or modifications not expressly approved in this manual could void your authority to operate and/or obtain warranty service for this equipment.

For Users in Canada: This digital apparatus does not exceed the "Class B" limits for radio noise for digital apparatus set out on the Radio Interference Regulations of the Canadian Department of Communications. Le present appareil numerique n'emet pas de bruits radioelectriques depassant les limites applicables aux appareils numeriques de la class B prescrites dans le Reglement sur le brouillage radioelectrique edicte par le ministere des Communications du Canada.

Table of Contents


Section 1: Unpacking and Setup	4
Section 2: Loading Label Stock and Arm Adjustment	5
2.1 Loading Label Stock.....	5
2.2 Application Arm Height Adjustment.....	12
Section 3: Label/Container Settings	13
3.1 Operating Basics	13
3.2 Die Cut/Reflective.....	14
3.3 Application Roller Position	15
3.4 Sensor Calibration	15
3.5 Label Position	16
3.6 Platform Position.....	16
3.7 Container Guide Adjustment.....	17
3.8 Platform Speed.....	18
Section 4: Applying Labels	19
Section 5: Container and Label Specifications	20
Section 6: Troubleshooting, Maintenance and Other Settings	24
6.1 Troubleshooting	24
6.2 Maintenance	25
6.3 Other Settings.....	25
6.4 Control Panel Functions.....	26
6.5 Technical Support.....	26
Section 7: Specifications	27
Appendix A: Label Path Diagram	28
Appendix B: Control Panel Flowchart	29
Index	30

Section 1: Unpacking and Setup

Thank you for purchasing the AP550 Label Applicator (hereafter referred to as "Label Applicator"). Boxes, bags, bins, bottles, packages, cans etc. will collectively be referred to as "containers."

The Label Applicator includes a Power Cord, 12 volt Power Adapter and the parts shown below. The Roll Bar, Roll Guides and Roll Drag Arm are located in the supply box along with the Power Cord. You will need to assemble them as shown. Attach the Power Cord and switch on the power as shown below. Remove all tape securing parts of the unit.


Place the unit on the back edge of a table at least 30" deep so that the Container Platform does not extend beyond the edge of the table when fully extended. This will prevent the platform from accidentally hitting the user during operation.




Section 2: Loading Label Stock

2.1 Loading Label Stock

1. Remove the Roll Bar and Roll Guides from the Label Applicator. The Roll Guides and Roll Drag Arm are removable and adjustable. They are held in place magnetically.




2. Remove one Roll Guide and the Roll Drag Arm from the Roll Bar.
3. Place the label stock roll on the Roll Bar with one side against the upright of the remaining Roll Guide. Place it on the Roll Bar with the loose end of the stock feeding over the top of the roll (labels facing up). The Roll Bar should be oriented with the holes to the rear as shown.




Tip! For narrow label rolls you may need to reverse the Roll Guides to allow the uprights to be placed next to the roll. (The bottom of the guides will face away from the roll on each side.)

4. Place the Roll Drag Arm under the Roll Bar. The Roll Drag Arm may be placed on either side of the Roll Bar but the rounded tip of the Roll Drag Arm should be located inside the core near the center. The arm is spring loaded so that there is downward pressure on the inside of the roll. This helps prevent problems toward the end of a roll.




5. Place the removed Roll Guide back on the Roll Bar and slide it close to, but not pinching the label stock roll.
6. Pull approximately 12" [30 cm] of label stock out beyond the front of the unit.
7. Remove approximately the first 15" [38 cm] of labels from the liner. This will be important later when you calibrate the label sensor to the label stock.




For additional instruction, see the diagram in Appendix A of this manual or the label attached to the left side of the applicator.


8. Push the label stock back until the leading edge of the stock is just before the Label Guide Roller. Push the Guide Collars to the sides so they are out of the label path. These will be adjusted later.



9. Use both index (pointer) fingers to roll the leading edge of the label stock UNDER the Label Guide Roller. Feed the stock forward until it enters the Sensor Housing.




Important Note: Do not feed the label stock into upper slot!



Label Guide Roller

Do NOT feed here!




Side View

Label Path

Sensor Housing

10. Continue feeding the stock in the same manner until it protrudes from the front of the unit.
Pull the remaining slack through the applicator.
11. Feed the leading edge of the label stock between the Liner Drive and Idler Rollers.




12. Feed the leading edge of the label stock under the stock coming off the roll. Align the leading edge of the label stock so that it is directly under the stock coming off the roll. Pull it tight.

Note: Make sure the stock is aligned so the labels pass under the line marked on the push bar. The line represents the location of the label sensor. Also, if the label stock has not been used before, make sure the first label does not extend beyond the Liner Drive Roller, as shown.


Distance from label stock to arm side plate should be equal in these locations.

Liner Drive Roller

Sensor Location Line




13. Once the upper and lower label paths are aligned, press up on the middle of the Liner Idler Roller firmly to lock the label stock in place. You will hear a "snap" when it locks into place.




14. Feed any remaining label stock over the Motor Cover, under the label roll and out the back of the applicator.

Important! As you apply the first few labels and more liner becomes available, make sure to route the excess liner off the table and toward the floor. The weight of the liner hanging to the floor will prevent the liner from bunching up and causing problems.




15. Move the Guide Collars so they are close to, but not pinching the label stock.



2.2 Application Arm Height Adjustment


The Application Arm basically consists of the upper half of the applicator. This entire assembly can be moved manually to four different positions to accommodate various container heights. The maximum container height is 8" [20 cm]. There is no minimum height other than the height required to make the container stiff enough for labeling.* To move from one position to another, squeeze the Pin Release Bar to move the pin out of the notch. Move the Application Arm up or down until the pin snaps into the desired notch.

Note: When moving the Application Arm from one position to another, be sure to maintain upward force at the front and rear of the arm. This will prevent the arm from falling when the Pin Release Bar is squeezed and it will allow the arm to move more easily.



* Containers less than 0.8" [2 cm] tall may require a riser to elevate the container above the back lip of the platform. This will prevent the forward-moving platform from hitting the Application Arm.

Important! Set the height of the Application Arm as low as possible without causing any part of the arm, other than the Application Roller, to touch the container or platform at any time during the application process. Keep in mind that the Application Roller is pliable and will flex during application.



Section 3: Label/Container Settings

3.1 Operating Basics

The AP550 has two common modes: Label Application Mode and Setup Mode. In the Label Application Mode, either the current label count or the current memory location is displayed. By default, the current label count is displayed. This allows you to keep track of the number of labels applied. To reset the label count to zero, press and hold the Recall/Reset button for two seconds. Similarly, press and hold the + or – buttons for two seconds to increase or decrease the label count.

The AP550 has ten different memory locations to store various label/container settings. During use, the unit must operate in one of ten available memory locations (0-9). The default memory location is “0”, but different memory locations can be used to store different settings for various label/container combinations. This allows you to quickly switch between common jobs.


To display the current memory location, press the Mode button. “F #” will be shown, where “#” is the location number. With the current memory location displayed, you can press the Recall/Reset button to index to any of the other nine memory locations. Press and hold the Recall/Reset button for two seconds to clear all the settings for the memory location currently displayed. Press the Mode button to return the display to the current label count, otherwise, after four seconds of inactivity the display will automatically revert back to the current label count.

To access the Setup Mode, first index to the desired memory location as described above. With the memory location still displayed, press and hold the Mode button for two seconds. The various settings will now be presented in the order shown in the following table. Press the Recall/Reset button to index through the settings. For some of the settings, the +/- buttons will change the values. Pressing the Mode button at any time will store the existing setup values and return the unit to the Label Application Mode. See the descriptions on the following pages for more details on each setting.

Note 1: Any changes made in Setup Mode will only apply to the current memory location. The settings in all other memory locations will remain unchanged.

Note 2: See Appendix B for a flowchart of the control panel menu.

To access the Setup Mode:



With label count displayed, Hold "Mode" for 2 seconds. press "Mode" once.

Below is a chart describing the label/container settings.



Text Displayed	Settings	Description
dIE/rEF	Die Cut / Reflective	Sets the label sensor for gap sensing or black mark sensing.
r-1 / r-2	Application Roller Position	Set to "r-1" for longer labels. Set to "r-2" for shorter labels.
SC-	Sensor Calibration	Calibrates the label sensor to the liner material.
LPo	Label Position	Sets how far the label protrudes from the peel edge.
PPo	Platform Position	Adjusts the Container Platform start point.
gPo	Guide Position	Moves platform out for Container Guide adjustment.
S-1 to S-8	Platform Speed	Sets the Container Platform return speed between S1 and S8. S1 is slowest. S8 is fastest.

3.2 Die Cut / Reflective

Die Cut (default): If you are using standard die cut labels that look similar to the labels pictured to the right, use this setting regardless of the size of the label. Also use this setting for through-hole label material where a hole is punched through each label or a notch is cut in the side (not common).

Reflective: Use "Reflective" for label material where a black pre-printed line (black mark) on the back of the label stock indicates the break between labels. Black marks are required on clear label stock or where the label waste matrix is left on the liner. Black marks can also be used for irregular-shaped labels or on any stock where the print starting position cannot be sensed using the label itself.

Die Cut Label Stock



Reflective Label Stock


3.3 Application Roller Position

r-1: The default Application Roller Position is r-1 which is the position furthest from the peel edge. The r-1 position is the most forgiving for container surfaces that are not completely flat. It also works with the widest variety of container heights.

r-2: The r-2 position should be used if you are using a shorter label that does not reach the Application Roller before falling off the liner. The label should always extend underneath the Application Roller so that the roller will press the leading edge of the label to the container when the arm is lowered.

To adjust the physical position of the Application Roller, remove the thumb screws on either side of the Application Arm. Push or pull the roller to align the thumb screw holes with the desired holes in the side plates. (The r-1 holes are closer to the front of the unit than the r-2 holes.) Replace the thumb screws.

Note: Make sure the physical position of the Application Roller always matches the setting selected.




3.4 Sensor Calibration

The Label Sensor must be calibrated to the specific label stock being used for each memory location. Use the following procedure to calibrate the applicator for your specific label stock/liner material:

1. Load the label stock as described in Section 2. Be sure to remove labels from the liner back to the Liner Drive Roller. For reflective stock, the black mark should be positioned directly under the Label Guide Roller. The goal is to feed only clean liner through the sensor area. This will give the sensor a good reading of the liner material.
2. Once the liner is loaded, follow the steps above to navigate to the SC- setting in the Setup Mode.
3. Lower the arm to trigger the calibration.
4. The label stock will move forward until the first label is presented for application.
5. Calibration for this liner is now complete and the values are stored in the current memory location.


Note: It is not necessary to recalibrate the label sensor between rolls of the same label stock.



For reflective stock, the black mark should be positioned directly under this guide roller.

3.5 Label Position

This setting will adjust the distance the label stock extends past the peel edge. You may adjust this setting ± 0.32 " [8.1 mm]. Use the \pm buttons to adjust the position. Press "Recall/Reset" to store the position in the current memory location. Depending on your container and the angle of the Application Arm, you may change this setting to achieve a more consistent label position on the container.




Note: For some thinner label stock, if the Label Position is increased too much, the label could fold or wrinkle at the leading edge.

3.6 Platform Position

The location of the label applied to the container in the direction of Container Platform movement can be adjusted by changing the start position of the platform. To determine the correct Container Platform start position:


1. Place your container on the platform, push the container back until it touches the back edge of the platform.



- At the "Platform Position" [PPo] setup option, press the +/- buttons to adjust the starting Container Platform position in 0.01" [0.25 mm] increments. Press and hold the +/- buttons to quickly adjust the position. The tray will move as you press the +/- buttons. Once the container is near the leading edge of the label stock, push down on the Application Arm to visually verify the correct position. In this mode the label will not apply. Readjust as necessary. The default position of the platform is 0.0" and will place the leading edge of the label about 8.0 to 9.0" [20 to 23 cm] from the back of the container. If you are applying a label to the front edge of a 6" container, for example, your platform position should be approximately 2.5" (8.5" minus container height = PPo setting). Press "Mode" or "Recall/Reset" to store this value in the current memory location.

3.7 Container Guide Adjustment

The Container Guide can be used to quickly and consistently position containers on the platform. The horizontal [side-to-side] location of an applied label on a container is determined by the horizontal position of the label stock in the Applicator Arm and the position of the Container Guide. At the "Guide Position" [gPo] setting, the platform will fully extend so you can access the Container Guide Thumb Screw on the underside of the platform. Loosen the Thumb Screw and move the guide to the appropriate position so that the container is in position to receive the label at the desired location. Retighten the Thumb Screw.



Caution: Stand clear of the front of the unit to avoid being hit by the platform as it extends.


Note 1: The platform can also be fully extended outside of the Setup Mode by pressing "Recall/Reset" and "-" simultaneously. Press the Mode button to reset the platform.

Note 2: You may also remove the Container Guide if your container is wider than the platform.

Note 3: You may also install an additional Container Guide (included) to hold containers more securely.

Note 4: The Primera Container Holding Kits can be used to hold odd-shaped containers or any smaller container in place. They are Primera part numbers 074398 and 074399.

Note 5: Either Container Guide can be oriented in either direction or removed entirely as needed for a given job.




Additional Container Guide Installation Instructions

The Container Guide included in this kit can be installed on the AP550 platform to more fully confine containers for accurate label placement. First, extend the platform completely by pressing "Recall/Reset" and "-" simultaneously. Remove the Thumb Nut and Metal Washer from the Container Guide (leave the Plastic Washer on the guide). Place the guide onto the platform. Add the Metal Washer from the bottom and then the Thumb Nut. Tighten the nut after moving the guide to the desired position.

3.8 Platform Speed


The Platform Speed setting controls the speed of the platform when it returns to the start position. S-1 is the slowest speed. S-8 is the fastest. Press "+/-" to select the desired speed. Press "Recall/Reset" to store the setting in the current memory location. Faster speeds will allow the platform to get into position for the next container more quickly. However, faster platform speeds may cause the platform to stall with heavier containers.

After completing the setup options you are now ready to start labeling your containers. The applicator accepts many types of flat or tapered containers. Please see Section 5 for complete container specifications.



Section 4: Applying Labels

1. Press the Mode button to display the current memory location.
2. If needed, press the Recall/Reset button to index to the desired memory location.
3. Assuming the desired label stock is loaded (see Section 2), place a container on the platform. Hold the container biased against the back edge of the platform and Container Guide until labeling begins.
4. Lower the Application Arm quickly until it touches the container. The platform and container will move toward you as the label is pulled from the liner at the peel edge. This motion will apply the label. **Maintain downward force on the arm until the label is completely applied.**



Note: If you stop or delay when bringing the arm toward the container, the label could be ejected before the arm reaches the container. Excessive force may cause the platform to stall.

6. Lift the Application Arm to return the platform to its starting position.
7. Remove the container and repeat the process.

The display will automatically indicate the number of labels applied. To reset the counter, press and hold the Recall/Reset button for two seconds.

Section 5: Container and Label Specifications

These specifications are provided for preliminary compatibility purposes only! Any questionable container/label combinations should always be tested by Primera Technical Support!

Container Specifications:

Length	0.75" – 12.2" [19 mm – 310 mm] (on platform) 12.2" [310 mm] – 18" [457 mm] (overhanging platform) 18" [457 mm] or greater with external support of hand or other mechanism that allows the platform to move
Width	0.75" – 12" [19 mm – 305 mm] (on platform) 12" [305 mm] – 18" [457 mm] (overhanging one side of platform) 18" [457 mm] or greater (overhanging one or both sides of platform* subject to weight restrictions below and external support, if needed.)
Height	0.8" – 8" [20 mm – 203 mm] **
Weight	20 lbs. [9.1 kg] ***
Shape	Flat, tapered front-to-back, flat front with rounded edges, cube, cuboid, cylinder on end, prism on end
Type	Tapered bottles, boxes, packages, bags, pouches, lids (canning-jar lids, jelly-jar lids, any flat lid), tins, bins, packages, cans, and many more.


* Container may extend over both sides of platform if Container Guide is removed.

** Flat containers/bags can be labeled if a 0.8" [2 cm] riser is used to raise the level of the container so the Application Arm does not interfere with the fixed metal guide on the back of the platform. The riser can be made from wood or any other solid material and secured to the platform if desired.

*** This is a recommended maximum based on a 20 lbs. [91 kg] container centered on the platform. Heavier containers and/or containers biased to the edges of the platform may work, but may shorten the life of the platform bearings.

Label Placement (Application Area)

Labels may be placed within the back 8" [20 cm] of any container. For example, an 18" long container that overhangs the front of the Container Platform can only have a label applied within the back 8" of that container which would result in a label that is not centered on the container.



Label and Roll Specifications


A wide variety of label stock can be used in the Applicator. Refer to the following specifications and settings before ordering custom stock from Primera or any stock from another company.

Important! Test all custom made label stock with the intended applicator before ordering large quantities!

Label Sensing Methods

Method 1: Label Gap Sensing

Method 2: Reflective/Black Mark Sensing
(Black Mark must be printed on back side of label stock)



Note: See table below for Max and Min values in inches and millimeters.

	Max	Min
Label Width	4.0" [101.6 mm]	0.75" [19 mm]
Liner/Media Width	4.125" [104.8 mm]	0.875" [22.2 mm]
Label Height/Length	6.0" [152.4 mm]	0.75" [19 mm]
Gap Between Labels	10" [253 mm]	0.1 [2.5 mm]
Reflective/Black Mark Width*	N/A	0.1" [2.5 mm]
Max Outer Diameter (OD)	8.0" [203.2 mm]	N/A
Inner Core Diameter (ID)	3.0" [76.2 mm]**	2.0" [50.8 mm]
Total Thickness (Liner + Label)**	0.010" [10 mil]	N/A

* The Reflective/Black Mark should be opaque to infrared light. The mark should be between the labels. The end of the mark should correspond with the beginning of the label.


** This is the recommended maximum. There are two factors that determine whether the applicator will accept any particular stock thickness:

1. The ability for the applicator to pull the paper through the drive rollers.
2. The ability for the sensor to read through the backing if the sensor is set to "Die Cut".





If you are using reflective label-sensing mode, number 2 does not apply. The fact that the sensor must read through the backing in die cut mode will limit the thickness much more than the applicators ability to pull the paper through the drive rollers. However, if you adjust the opacity level of the liner enough to allow the label to be seen by the stock sensor, the thickness will only be limited by the applicators ability to pull it through the drive rollers. For these reasons the weight or thickness of the liner is a variable that cannot easily be defined. Primera recommends and uses 40# liner with all label stock. **It is important to test all label stock with the intended applicator before ordering large quantities!**

*** Inner core diameter can be greater than 3.0". However, as the inner core diameter increases beyond 3.0" the acceptable outer diameter decreases. If there is any doubt, contact Technical Support to test the label stock.

Roll Specifications



Label Copy Position Chart

Copy positions 1-4 (labels wound out) - compatible with the AP550	
	1. Top of copy dispenses first.
	2. Bottom of copy dispenses first.
	3. Right side of copy dispenses first.
	4. Left side of copy dispenses first.
Copy positions 5-8 (labels wound in) - NOT compatible with the AP550	
	5. Top of copy dispenses first.
	6. Bottom of copy dispenses first.
	7. Right side of copy dispenses first.
	8. Left side of copy dispenses first.

Section 6: Troubleshooting, Maintenance and Other Settings

6.1 Troubleshooting

Multiple labels feed from the Application Arm, with or without platform movement.

Calibrate the label sensor. (See Section 3.4.)

Display flashes "SC-" when I try to apply a label.

Calibrate the label sensor. (See Section 3.4.)

Labels are applied to the container crooked.

1. Check for container taper. Some containers may have a slight taper that will cause the label to be applied crooked. Make sure your container is oriented so the taper is from front-to-back or back-to-front, NOT side-to-side. You may also choose to install a wedge on one side or the other to make the container level from side-to-side.
2. Roll Guides should also be positioned very close to the roll, but not squeezing any part of it (so the roll has very little, but at least some side-to-side play between the guides). For larger, heavier rolls make sure that the roll is positioned on top of the Roll Guides with the magnetic portions facing in. This will minimize the chances that the heavy roll will push the guides out of place.
3. Make sure the Roll Drag Arm is in place as described in Section 2.1.4.
4. Make sure the label stock runs parallel to the Application Arm. (See Section 2.1.12.)

Label position on container varies, side to side, from container to container.

Make sure the label stock is running parallel to the Application Arm (See Section 2.1.12.) and the Roll Guides and Guide Collars are close to, but not pinching the label stock. Make sure the thumb screw holding the Container Guide in place is tight. Also, be sure to hold the container tight to the guide until labeling begins.

Label position on container varies, top-to-bottom, from container to container.

Lower the Application Arm height. (See Section 2.2.) Change the Application Roller Position and/or the label distance from the peel edge. (See Section 3.3 & 3.5.) The optimal roller/label position is determined by the angle of the arm during application and the various properties of a particular label/container combination. Experimentation may be necessary.

Leading edge of labels fold as they are applied to the container.

Decrease the label distance from the peel edge. Some thin polyester and polypropylene label materials do not have enough stiffness and can droop down from the peel edge if the label position is set too high. This can cause folding at the leading edge of the label. (See Section 3.3 & 3.5.)

There are bubbles or wrinkles in the label.

Wrinkles or bubbles can appear on the applied label if the container is not smooth or has bumps or ridges. To minimize bubbling or wrinkling, adjust the Application Roller position and/or the Label Position. (See Section 3.5.)

Container Platform is stalling, scraping, or squealing.

An Application Arm position that is too low or excess pressure on the Application Arm Push Bar can cause the platform to stall. Roll Guides and/or Guide Collars that pinch the label stock can also contribute to stalling. After checking and correcting these items, if the platform still stalls or if scraping or squealing is detected, replace the Platform Bearing Plate. (See Section 6.2.)

6.2 Maintenance

Liner Rollers

When not in use, leave the Liner Idler Roller in the unclamped position. This will minimize the possibility that permanent indentations will be made in the Liner Drive Roller. If any label jams occur, be sure to remove any labels and/or adhesive from both of these rollers.

Lubricating bearings

Primera recommends oiling the four bearings associated with the Liner Drive Roller and Liner Idler Roller. Oil these four bearings once every 50,000 containers labeled. They should only be oiled after the first 50,000 containers as they are lubricated with a special grease at the factory. One drop of any machine oil or motor oil for each bearings should be adequate. This maintenance is optional but will increase the life of the applicators for heavy users who use the applicator for several hours each day.

Replacing the Platform Bearing Plates

The Platform Bearing Plates ride against the Platform Shafts and are subject to wear. They will likely last from 100,000 containers to 1,000,000 containers depending on the weight of the containers used. As they wear, eventually the front of the Container Platform will ride low enough to scrape against the Base Plate. At that point, the parts would need to be replaced. They are mounted by two screws that can be accessed with the platform extended.

Platform Bearing Plate: Primera Part # 691306

6.3 Other Settings

Setting the LED display intensity

- 1) Press and hold the Mode and + button until the display shows "LED".
- 2) Then press the + or – buttons to adjust the LED intensity.
- 3) Press the Mode button to accept.

Moving tray to "out" position


Press and hold the Recall/Reset and – button simultaneously. The tray will move to the "out" position.

Setting English or metric units

English

- 1) Turn off the unit.
- 2) Press and hold the Mode button and the + button simultaneously while switching on the unit.

Upon start up, the first digit will display as a "-" followed by the current firmware version.




English

Metric

- 1) Turn off the unit.
- 2) Press and hold the Mode button and the – button simultaneously while switching on the unit.

Upon start up, the first digit will display the upper and lower segment followed by the current firmware version.



Metric

Test Mode

- 1) Turn off the unit.
- 2) Press and hold the Recall/Reset and + button while switching on the unit.
- 3) The unit will now move the platform in and out and run the liner drive roller continuously.

Note: Be sure to unload any label stock from the Liner Drive Roller before starting the Test Mode.

Turning Test Mode off

- 1) Turn off the unit.
 - 2) Press and hold the Recall/Reset and – button while switching on the unit.
- Test Mode will be disabled.

6.4 Control Panel Functions

Mode Button: Toggles the display between the label count and the current memory location. Hold for two seconds to enter the Setup Mode for the currently displayed memory location. Press to exit the Setup Mode.

Recall/Reset Button: Displays next memory location in Memory Mode. Indexes to the next parameter in Setup Mode. Hold for two seconds to reset the label counter when in Label Count Mode. Hold for two seconds to clear all the settings for the current memory location.

+ Button: Increments the current parameter when in Setup Mode. Hold to advance more quickly. When the label count is displayed, hold for two seconds to increase the count.

– Button: Decrements the current parameter when in Setup Mode. Hold to advance more quickly. When the label count is displayed, hold for two seconds to decrease the count.

6.5 Technical Support

If you have difficulties operating your applicator, the procedures in this manual and the software User's Guide should, in most cases, solve the problem. If you still have difficulty, contact Primera Technical Support using one of the methods listed below.

Source	Location
Primera Knowledge Base	www.primera.com/knowledgebase.html
Email Support	www.primera.com/contact_tech_support.cfm
Phone Support	763-475-6669 (Mon - Fri 8 a.m. - 6 p.m. CST)


Section 7: Specifications

Container Platform	12" W x 12.2" D [305 x 310 mm] *
Container Height	.002" - 8" [0.05 mm - 203 mm] **
Container Shape	Flat, tapered front-to-back, flat front with rounded edges, cube, cuboid, cylinder on end, prism on end
Label Width	0.75" - 4" [19 mm - 101.6 mm]
Label Height	0.75" - 6" [19 mm - 152.4 mm]
Label Liner Width	0.875" - 4.125" [22.2 mm - 104.8 mm]
Label Placement	Leading edge up to 8" [203 mm] from trailing container edge
Label Roll Diameter	8" [203 mm] (maximum)
Label Roll Core	2" - 3" ID [50.8 mm - 76.2 mm]
Electrical Rating	12 VDC, 5.0 A
Power Requirements	100-240 VAC, 50/60 Hz, 1.7A
Agency Certifications	UL, UL-C, CE, FCC Class B
Weight	24 lbs [10.9 kg]
Dimensions	12" W x 21.3" D x 10.1" - 15.4" H [305 x 541 x 256 - 391 mm]


* Container may overhang platform to the front and/or either side.

** Containers shorter than 0.8" [20.3 mm] may require adaptive spacers. Some very short containers may not be stiff enough to support label application.

Label Path Diagram



Appendix B: Control Panel Flowchart



Index

Application Roller.....	12, 15
Container Guide.....	17
dIE (Control Panel Display)	14
Die Cut.....	14
English	25
gPo (Control Panel Display).....	14
Label Position.....	16
LPo (Control Panel Display).....	14
Memory Location.....	13
Metric.....	25
Platform Position.....	16
Platform Speed	18
PPo (Control Panel Display).....	14
r-1 (Control Panel Display).....	14
r-2 (Control Panel Display).....	14
rEF (Control Panel Display)	14
Reflective	14
Roller Position.....	15
SC- (Control Panel Display)	14
Test Mode	26
Thumb Screw.....	15, 17
Sensor Calibration.....	15

