



MOD-PRIVACY POST

Assembly Instructions

Unpack all contents

Contents:

- 1-Post Upright
- 1-Post Base
- 4-Post Loop Connectors
- 8-White Rivets
- 1-Pop Rivet Tool



Step 1

Remove nose piece from rivet tool and replace with middle nose piece on the tool shaft.



Step 2

Slide Post Upright onto Post Base. Ensure holes on Post line up with the holes on Base.



Step 3

Align post loop connectors with bottom and top holes. Rivet Loop Connector to Post using 2 Rivets per on both sides.



You have now successfully built your Mod-Privacy Post!

Questions?

Reach out to our Customer Support team at:
Sales@mod-fence.com
562-269-1411
mod-fence.com

