

## **Instructions for Assembling Dispenser**

- Cut the bottom of plastic sleeve on cones, at pointed end. Insert into colored base then pull plastic up and off of cones.
- 2. With one hand, hold the row of cones in place (in base) then with the other hand, slide clear plastic tube over entire sleeve of cones and lock into coupler. It is not necessary to remove white plastic cap.
- 3. Remove cones by grasping cones gently from bottom and pushing forward and pulling down.
- 4. If cones fall through, place fewer cones in the plastic sleeve.