



ECO SCOOP SHOWER INSTALLATION INSTRUCTIONS

Due to variations in local codes, this unit should be installed by a licensed plumber. If mounting on a cabinet, confirm with manufacturer for correct placement.

1. After removing the Eco Scoop Shower from carton, determine where you will be attaching the unit.
2. Using the unit as a template, hold in the desired mounting location and scribe the 4 screw holes, making sure there are no wires, pipes, and/or other obstructions behind the hole marks.
3. Drill 4 pilot holes using a #29 bit.
4. Secure the unit with the self-tapping screws provided to the cabinet or wall.
5. Attach the 6 foot steel mesh hose provided to the second elbow on the underside of the Scoop Shower sink and tighten with wrench. This connects to your freshwater line using adapter provided. The black knob on left controls the amount of water supplied and can be adjusted to suit your needs.
6. Install ¾" ID vinyl tubing (not included) to the barb fitting for the wastewater drain.