



1

CONNECT THE FEET TO BARRIER.

2

INSERT THE HARDWARE.



3

SECURE THE HARDWARE IN PLACE.
YOUR BARRICADE IS NOW READY
TO USE.



CONVENIENT

HOOK-AND-LOOP FASTENING SYSTEM
FOR A SEAMLESS CONNECTION

