

Camdolly® CDR2020 Assembly Manual

1. Push (4) casters fully into (4) white cap holes, as shown in the illustration.

Note:

Make sure you push the casters all the way into the bushing.

STEPS FOR OPTIONAL HANDLE

2. Place tubular handle into 2 slot holes at the bottom side of the dolly, as shown in the illustration.
3. Screw (4) No. 10 3/4" sheet metal screws into the small holes on the two handle slots.

