

Dome-D-Lock Installation Guide

Tools Needed

The following tools to properly secure the Guardian Dome-D-Lock:

- 3/8" Ratchet
- 3/8" Ratchet Extension
- Tamperproof Torx Key (T-40 for 2" and T-45 for 3" & 4" drain-locks)
- Rag

How to Install

- Clean the floor sink of debris and grime build up within the throat of drain. (Photo#1)
- Determine the appropriate size Guardian Dome-D-Lock to be installed: 2", 3" or 4". If any of these sizes do not fit in your floor sink contact TNT Products at 818-515-1001. Once size is validated, place the Dome-D-Lock in the hole of the floor sink. Note: The rubber band on the black skirt can be removed to allow for a better fit.



Photo#1

- Assemble the ratchet, ratchet extension and tamperproof key. Determine which tamperproof key will be needed to secure the desired Dome-D-Lock. T-40 key for 2" and T-45 for 3" and 4".
- While holding down the Dome-D-Lock with one hand, insert the driver and key into the tamperproof bolt and tighten (clockwise) until firmly secured. Do not over tighten use judgment. (Photo #2)
- All locations are built differently and may need additional tools to reach the floor sink. Floor sinks may also differ in shape not allowing for the Guardian Dome-D-Lock to fit properly. If this is the case for you, contact TNT Products at 818-515-1001.



Photo#2

Monitoring the Dome-D-Lock

- Once the Dome-D-Lock is properly secured and locked there should be no need to remove it other than for sanitation purposes. As needed use soapy hot water and a plastic brush to clean any built of grime. If the Dome-D-Lock is to be removed for cleaning; wash it by hand at the nearest dump sink or run it through your dish machine. Before re-installing make certain all parts are in good condition.
- Monitor that your Guardian Dome-D-Lock's are in place and secured/locked in place once a month to guarantee protection of your drain pipes.