

Drop-in Ice Bin

Assembly Instructions

TOOLS REQUIRED (not included)

Pencil
Saber saw, keyhole saw, or router
Power drill
Silicone caulk
Safety glasses and cut-resistant gloves
Wrench

PARTS:

- Ice Bin
- Weld studs and brackets
- Cutout Template



Assembly Instructions

Remove all contents from carton. Inspect the ice bin for any damage prior to installing. Damaged units should not be installed.

1. Place ice bin cutout template at desired location on countertop. This should be cut out along the indicated cut line. Ensure front edge of the ice bin is parallel to the countertop edge.
2. Using a pencil, carefully trace along the cutout template cut line onto the countertop. Remove the template from the countertop.
3. Drill a pilot hole inside the cut line.
4. Place the saw inside of the pilot hole and carefully saw along the cut line.
5. Remove the countertop cutout section.
6. Align the ice bin in the open space to mark where the four weld studs need to be drilled into the counter.
7. After marking, drill through the counter for each corner of the ice bin.
8. Apply sealant around the perimeter of the ice bin cutout. Carefully place the ice bin in the cutout hole.
9. Slide the brackets over each weld stud and screw on the nuts.
Use a wrench to tighten each nut to secure the ice bin to the countertop.
10. Clean away any excess caulk or debris with a cloth.
Install drain(s).

