

STEP 7. INSTALLING TOILET PAPER HOLDER AND ROD.

Parts required:

- Toilet paper holder (2 or 3 roll)
 - Toilet paper rod (2 or 3 roll)
 - 6- Rivet large flange 3/16" (only 4 needed for 2-roll holder)
 - 6- Rivet washer 3/16" stainless steel (only 4 needed for 2-roll holder)
1. Using 3/16" drill bit, drill the predetermined holes on side panel.
 2. Align holder with holes in side panel and drill holes in holder.
 3. Insert rivets from outside the toilet through the holes in toilet wall and toilet paper holder. Place rivet washers over ends of rivets and secure using rivet gun/ rivet tool.
 4. Insert toilet paper rod through holes on sides of toilet paper holder and secure with zip strap or lock of choice.

