

Mounting Instructions for Dispenser Security Enclosure

Contents:

- 1 Steel Dispenser Cover w/ Barrel Lock
- 1 Barrel Key
- 3 Logoed Decal Stickers (GOJO®, PURELL® and PROVON®)

Tools required:

- Pencil
- Drill w/ appropriate size bit
- Phillips or nut driver bits for hardware

Recommended Mounting Hardware (not included):

- Drywall – 3/16" x 1-1/2" toggle bolts
- Drywall & Wall Stud - #10 x 1-1/2" pan head screw
- Masonry or Brick – 3/16" x 1-1/4" tapcon-style masonry screw



Step 1: Place metal cover on wall in desired location. Make sure metal cover is straight and level. Using the metal cover as a template, mark the 4 metal cover mounting holes around the outer edge of the cover. Mark the 3 dispenser mounting holes on the wall.



Step 2 (not pictured): Set metal cover aside. Drill pilot holes with appropriate size drill bit per the recommendations of the fastener manufacturer.



Step 3: Hold metal cover up to the wall and secure with recommended fasteners per manufacturers instructions.



Step 4: Place dispenser in metal cover, lining up with 3 dispenser mounting holes inside metal cover. Secure with recommended fasteners.



Step 5: Close dispenser cover and metal cover. Verify that assembly is securely mounted to wall.



Step 6: Place corresponding GOJO, PURELL or PROVON label on metal cover. Open dispenser and insert refill. Close covers and lock metal cover with provided key.