Instaining Colo Pair.

3. Apply a generous bead of silicone sealant to underside of mounting flange before setting unit into cutout. Remove any excess sealant from top flange and countertop.

4. Connect 1 inch drain to drain pan or floor drain.

Consult local codes for approved drain connections.

VOLTS	НР	AMPS SINGLE PHASE			REFRIGERANT		DESIGN PRESSURE		POWER
		LRA	MFS	L1-N	TYPE	QUANTITY	HIGH	LOW	SUPPLY CORD
115	3/4	59	30	15.3	R-404-A	54 OZ	500	174	NEMA 5-20P

