

1. Carefully clean the parts to be repaired.
2. Shake the resin thoroughly
3. Transfer the powder paint from the cardboard tube into a separate container/plate and dilute it with the provided resin (be careful not to use too much resin, just enough to dissolve the powder)
4. Apply the mixture obtained on the parts to be retouched using an appropriate brush
5. Wait for the applied solution to polymerize.

**DANGER** - Easily flammable liquid and vapors

May cause a skin allergic reaction. It causes severe eye irritation. Harmful if inhaled. It can irritate the respiratory tract. Keep out of reach of children. Keep away from heat sources, hot surfaces, sparks, open flames or other sources of ignition. Wear protective gloves, protect your eyes, and face. In case of fire: use carbon dioxide, dry extinguishing powder, foam to extinguish. Store in a cool and well-ventilated place. Dispose of the product and container in a collection center for hazardous or special waste according to local and national regulations.