

# Undermount Sink Instruction Guide



2.



3.



3.



4.



5.

- Find the undermount cutout templates on your item's product page under resources.
- Metal edges may be sharp. Handle with caution.
- It is recommended that this product be installed by a qualified installer.
- Be sure to follow all local plumbing and building codes.
- Inspect sink for damage before installation.
- Safety goggles and gloves should be worn during installation to prevent personal injury.

## Tools Required (not included):

- Safety Glasses
- Silicone Caulk
- Pencil
- Cut-Resistant Gloves
- Power Drill
- Saber Saw, Keyhole Saw, or Router

1. Remove all contents from carton. Inspect the sink for any damage prior to installing. Damaged units should not be installed.
2. Place sink cutout template at desired location on countertop. This should be cut out along the indicated cut line. Ensure front edge of the sink is parallel to the countertop edge.
3. Once traced, cut a hole in the countertop to fit the sink. Pre-drill mounting holes under the countertop.
4. Apply silicone caulk evenly around the top of the sink flanges. Position and align the sink under the countertop opening. Press the silicone and flange up onto the countertop.
5. Check alignment of the sink to the countertop opening and then tighten the fasteners into pre-drilled holes until the sink is tight against the countertop. Do not over tighten.
6. Clean away any excess caulk or debris with a cloth. Install drain(s) and faucet(s).