

7502 & 7503

Adjustable Partition Hangers

Kit:

- (1) Plastic Holder
- (1) Metal Hook
- (2) Screws

Tools needed for assembly:

Phillips Screwdriver

1. Your new partition hanger will adjust to fit partitions that are 1-1/2" - 3" in width. To assemble the hanger, first remove the two screws from the metal hook. See Illustration 1. Then position the plastic holder and the metal hook as shown in Illustration 2.
2. There are two hole locations in the top of the metal hook. Location "A" will be used if your partition is wide. Location "B" will be used if your partition is narrow.
3. If you are not sure which hole to use for assembly, simply hold the two pieces together on top of your partition and use the hole that lines up in the top slot on the plastic holder. See Illustration 2.
4. Insert the screw thru the adjustment slot and tighten down. Your new hanger should fit snug against both sides of the partition.

