



Griddle Kleen

Loosens And Lifts Baked-on Food & Grease
From Griddle Surfaces • Heat Activated

Net Contents: 1 Quart (32 fl. oz.)

DIRECTIONS FOR USE

1. Pour **GRIDDLE KLEEN** evenly over hot (300-350°F) griddle surface.
2. Immediately spread **GRIDDLE KLEEN** over entire surface and scrub as needed.
3. Wipe or scrape into grease trap.
4. Turn off griddle and wait to cool.
5. Rinse surface and wipe clean with a thick, damp cloth.
6. Apply a thin coating of liquid shortening to prevent surface from rusting.

WARNING

HAZARD STATEMENTS

- Causes serious eye irritation
- Causes skin irritation

KEEP OUT OF REACH OF CHILDREN

PRECAUTIONARY STATEMENTS

Prevention: Wear protective gloves/eye protection/face protection. Wash hands thoroughly after handling. **General Advice:** None. **Eyes:** IF IN EYES: Rinse cautiously with water for several minutes. Remove contact lenses, if present and easy to do. Continue rinsing. If eye irritation occurs: Get medical advice/attention. **Skin:** IF ON SKIN: Wash skin with plenty of water. Take off contaminated clothing and wash before reuse. If skin irritation occurs: Get medical advice/attention. **Inhalation:** None. **Ingestion:** None. **Fire:** None. **Spills and Leaks:** None. **Storage:** None. **Disposal:** None.



INGREDIENTS: GLYCEROL (CAS# 56-81-5), WATER (CAS# 7732-18-5), POTASSIUM CARBONATE (CAS# 584-08-7), SODIUM BICARBONATE (CAS# 144-55-8), AUGEO MULTI (CAS# 100-79-8), POLYACRYLATE (CAS# NA), SODIUM METASILICATE (CAS# 6834-92-0), COLORANT



Distributed by:
Noble Chemical, Inc.
2205 Old Philadelphia Pike
Lancaster, PA 17602

For customer service or for
more ingredient information visit:
www.NobleChemical.com or
call: 1-888-256-6400



999GRIDLKLN



4 00013 50460 9

