Trouble Shooting Guide for Bobrick B-824 SureFlo® Automatic, Top Fill Bulk Liquid Soap Dispenser

	If motor running and LED lights up.								
	Likely Cause	Action	Instruction	Replacement Part/Kit Needed					
Unit Not Dispensing	Clogged Nozzle Tip and Mesh Screen.	Remove Nozzle Tip.	Clean Nozzle by soaking in warm water and replace. Flush whole system. If Nozzle continutes to be clogged replace.	824-210					
	Soap may be too viscous.	Ensure that soap meets specified viscosity range. Viscosity less than 100cps (CPS = centerpoise) Adjust viscosity and Flush system.	Replace with new soap.	n/a					
	If unit requires multiple (more than 5) activations to dispense liquid. Duckbill or O-Ring missing or not installed properly.	Unscrew Bottle Cap and remove Bottle. Check Duckbill Valve and O-Ring are in correct location. Disconnect fiber optic cables from Bottom Housing.	Re-Insert Duckbill Valve and O-Ring. Found in Retianer Back #10 on parts list. Refer to step 7 on installation instructions. Screw Bottle Cap back on Bottle. #8 on parts list. Re-connect fiber optic cables from Bottom Housing. #19 on parts list.	824-101 824-70 824-204					
	No change.	All steps above completed.	Return entire unit to manufacturer.	B-824					
	If motor not running and LED lights up.								
	Likely Cause	Action	Instruction	Replacement Part/Kit Needed					
	Issue with Power Source this is determined by Flasing RED LED.	Check batteries. Check A/C adapter connection.	Replace with new batteries. Reconnect A/C adapter connection. If problem persists, send unit back to manufacturer.	n/a					
	Gear jamming.	Check for dried soap. Purge system.	Open Cover and pour warm water and then purge.	n/a					
	Flashing green LED. Indicates sensor obstruction.	Ensure all obstructions have been removed from sensor path.	Refer to mounting template.	824-207					
	No change.	All steps above completed.	Return entire unit to manufacturer.	B-824					
	If motor not running No LED light.								
	Likely Cause	Action	Instruction	Replacement Part/Kit Needed					
	No power to the unit	Replace with new batteries. Check A/C adapter connection.	If problem persists, send unit back to manufacturer.	n/a					
	No change.	All steps above completed.	Return entire unit to manufacturer.	n/a					
200	Likely Cause	Action	Instruction	Replacement Part/Kit Needed					
35	Loose bottle connection to	Unscrew bottle.	Ensure the gaskets and washer are installed properly see page 2. Re-	n/a					
Unit Leaking	Bottom Housing.		install and tighten bottle cap.						

B-824 Parts List:

Item Description

1	Top Assembly with Spout, Door, Shank, and fiber optics	824-251	Γ	1		Door 7	2 03
2	LED Light Pipe			2			1 1 1 1 1 1 1 1 1 1
3	Liquid Nozzle Tip	824-234		3 4		○ ← 23	24
4	Fiber Optic Insert				5		
	with Sensor Lenses	824-229			6 →		<i>Do</i>
5	Rubber Counter Gasket	824-74			7-	#1	
6	Wave Washer	824-109	1			#	25
7	Mounting Nut	824-68	' 🗍				
8	Bottle Cap	824-70					
9	Retainer	824-155					
10	Retainer Back	824-101			////	8	
11	Screw	824-162		ę	9		
12	Rubber QC Gasket	824-110					
13	Stainless Steel Washer	824-480			11	→ 10	
14	Rubber QC Gasket	824-110				● ← 12	
15	Adapter	824-137				─ 13	
						─ 14	
16	Bottom Housing Assembly					15	
	(includes Soap Bottle)	824-204					
17	Battery Pack (Requires (4) "D" cell alkaline	824-45					
	batteries not included)				//	,'	
18	(3) Fiber Optic Cables for Sensor				11	NOK	W 17
	and LED Light Pipe				ВОВК	ATCK)	
19	Fiber Optic Connector Tip Assembly		16		1 1		<u> </u>
20	Fiber Optic Nut		16 —			Λ	26—
21	Portion Control Knob			18			20
22	Automatic System Flush Button			¥ - 1 - 1 - 1 - 1 - 1 - 1 - 1 - 1 - 1 -			
23	Key Hole				* 19	///	
24	BobKey	24-17		\			
25	Fiber Optic Cable Cover					22	
26	Mounting Template	824-207		20—((())		21	Optional
27	Optional: A/C Adapter Kit with U. S. Plug	3974-57					W.
	Optional: A/C Adapter Kit						
	with U. S. Plug for UK, Europe						
	and Australia, order additional plug kit	3974-58					
	F3	50					

