

## AURA WIDE AREA VACUUM Parts Manual

## INTRODUCTION

## OPERATING & MAINTENANCE INSTRUCTIONS

## **READ THIS BOOK**

This operator's book has important information for the use and safe operation of this machine. Read this book carefully before starting the machine. Keep this book and tell all operators to read the book. If you do not follow the instructions, you can cause an injury or damage equipment, furniture or buildings.

For new books write to:

Pacific 2259 South Sheridan Road Muskegon, MI 49442

Carefully inspect all components to ensure that there is no concealed freight damage. If such damage is discovered, file a "CONCEALED DAMAGE REPORT" immediately with the delivering carrier. The contents of this manual are based on the latest product information available at the time of publication. **Pacific** reserves the right to make changes or improvements to its machines without notice.

FOR YOUR CONVENIENCE, RECORD THE FOLLOWING IMPORTANT INFORMATION:

MODEL	
SERIAL NUMBER	
PART NUMBER	
DATE DI IDCHASED	