

CatalogModelWDM120SameWDM120GRWDM120



		www.waringproducts.com
Illustration #	Part # 030682	Description Switch Boot
2	030683	Rocker Switch
3	016236	Hex Nut
4	030684	Switch Plate
5	030685	Hole Plug (4 required)
6	033901	Screw (4 required current production)
	030686	Screw (4 required)
7	034298 034297 030687	Top Housing with PC Holder (current production) Top Houing (current production) Top Housing
8	034300	PC Holder
9	033886	PC Holder Screw
10	033899 030688	Toggle Switch (current production) Toggle Switch
11	034408	Green/Yellow Ground Lead (current production)
12	033888	Toggle Switch Black Lead Harness (current production)
13	033889	PC Board (current production)
14	033890	PC Board Screw (2 required current production)
15	030708	Cable Clamp (current production)
16	033900	Clamp Screw (current production)
17	030702	Clamp Washer (current production)
18	030689	Name Plate
19	030691	Nameplate Screw (2 required)
20	030690	Nameplate Washer (2 required)
21	030692	Front Housing
24	030694	Top Motor Mount
25	033893 030695	Motor (current production) Motor
26	030686	Motor Screw (2 required)
27	030696	Motor Washer (2 required)
28	030697	Side Motor Mounts (2 required)
29	030716	Solid Agitator

CatalogModelWDM120SameWDM120GRWDM120



Illustration #	Part #	Description	
30	029291	Solid Agitator Screw	
31	012409	Crimp Connector (2 required)	
32	013731 013731	Wire Ties (4 required current production) Wire Ties (3 required)	
33	030699 031978	Actuator Switch with Switch Bracket and Metal Plate Actuator Switch with Switch Bracket	
34	030700	Actuator Bracket Screw (2 required)	
35	030701	Spring	
36	030686	Actuator Switch Screw (2 required)	
37	030702	Actuator Switch Washer (2 required)	
38	030703	Actuator Switch Sleeve (2 required)	
39	030704	Cup Support Locking Assembly	
40	033901 030700	Screw (2 required <i>current production</i>) Screw (2 required)	
41	030706	Ground Screw	
42	030707	Ground Lock Washer	
43	030708	Cable Clamp	
44	030686 030700	Clamp Screw (current production) Clamp Screw	
45	030702	Clamp Washer (current production)	
46	033898 030713	Hex Nut (4 required current production) Hex Nut (4 required)	
47	033897 030714	Large Washer (4 required current production) Spring Washer (4 required)	
48	034306 030710	Bottom Plate Weight (current production) Large Plate Weight	
49	033895	Bottom Plate Bracket (4 required current production)	
	030711	Small Plate Weight (2 required)	
50	033969 030700	Screw (2 required for each bracket <i>current production</i>) Screw (2 required for each small plate weight)	
51	030707 030707	Lock Washer (2 required for each bracket <i>current production</i>) Lock Washer (2 required for each small plate weight)	
52	030719	Foot (4 required)	
53	030696	Foot Washer (4 required)	



		www.warmgproducts.com			
Illustration #	Part #	Description			
54	030715	Foot Screw (4 required)			
55	033969	Weight Plate Screw (2 required current production)			
56	033901 030686	Bottom Plate Screw (4 required current production) Bottom Plate Screw (4 required)			
57	034307 030712	Bottom Plate (current production) Bottom Plate			
58	031985 030709	Cord (current production) Cord			
59	031984	Strain Relief (current production)			
60	030705	Back Housing			
61	033901 030686	Back Housing Screw (6 required current production) Back Housing Screw (6 required)			
62	030717	Cup Actuator			
63	030718	Cup Support			
032616 - Metal Plate 032617 - Screws (2 required) 031978 - Actuator Switch with Switch Bracket					
Parts of 030699 030709 Cord (older units) 030710 Large Weight Plate (older units) 030698 Small Weight Plate (older units) 030698 Motor (older units) Switch Lead w/Connector (older units)					