## Hardware preparation:


- 1. Connect the printer to the computer using the USB.
- 2. Install the printer's driver.
- 3. Run the Bridge Printer Installer, follow the instructions and wait until the software be installed.
- 4. Connect the scale to the PC and wait until the USB driver be installed.

## Software using:

1. Locate the Bridge Printer software and execute it:



2. The Bridge Printer interface will be opened:



3. Select your scale model using the "Scale Model" drop-down list:



4. Select the COM Port assigned to the scale and press "Connect":



5. Search and select your printer in the "Select Printer" drop-down list:



6. Edit your business name and webpage using the "Edit" buttons:



7. Type the name of your first product:

Item			
Apple			
11/21/2017 15:38:59	Ticket ID:	0	Reset

8. According to your scale model please follow the steps:

PC and LPC models:

- Place the product in the scale's platform.
- Type the unit price, then press key.
- The scale will send the weight, unit price and total price to the software.
- If you need to add more products, edit directly the Item description and repeat the previous step.
- Once you had finished to add products, you must to press key while the total sum be displayed:



- The printer will print a ticket like this:




## LEQ model:


Place the product in the scale's platform.



The scale will send the weight data to the software and the printer will print a ticket like this:



- If you need to add more products, edit directly the Item description and repeat the previous step.
- 9. The software haves a counter that will show the quantity of tickets that you had printed. Also, you can check the "Copy" option in order to print a copy of the ticket.



Use the "Reset" button to reset the Ticket ID counting.