




Salad Spinner/Dryer

2.5 & 5 Gallon with Brake and Handle

#181BSD25GL, #181BSD5GL

Includes



Directions

1. Slide and affix the drain tube (provided) onto the bottom of the spinner.
2. Place the drain tube in a bucket or the sink.
3. Press the spinner firmly onto the surface to fasten the suction cups.
4. Remove the cover from the salad spinner.
5. Place washed lettuce in the basket.
6. Affix the cover to the spinner.
7. Rotate the handle in either direction to commence spinning action for 10-20 seconds.
8. When done spinning, press the white BRAKE button to stop the basket from spinning.
9. Remove perforated inner basket by lifting up and out, dump lettuce into a clean container.
10. To release suction cups, pull the tabs on them up and away from the surface of the table. *Do not lift off table without releasing suction, otherwise damage can occur.*
11. Rinse the spinner with hot water and detergent to clean.

Cleaning Instructions

Remove all remaining salad and rinse the spinner with hot water and detergent.

WARNING

- Hold the salad spinner securely while spinning.
- Do not remove the cover while spinner is functioning.
- Keep your hands away from the rotating handle.