


Remove all items from the carton . Verify all pieces before assembly.


PART LIST

KEY	QTY	DESCRIPTION	KEY	QTY	DESCRIPTION	KEY	QTY	DESCRIPTION
1	5	Caster	8	2	Armrest	13	1	Seat
2	1	Base	9	2	Arm Width Adjustment Knob + Washers	14	1	Backrest Post Bellow
3	1	Seat Post	10	2	Arm Bracket	15	2	Backrest Post Bellow Screw 4x16mm
4	1	Seat Post Cover	11	1	Mechanism	16	1	M5 Size Allen Wrench
5	1	Backrest	12	1	Backrest / Mechanism Bolt 10x25mm +Washers	17	1	M6 Size Allen Wrench
6	1	Backrest Post						
7	1	Backrest Screw 8x10mm						


STEP 1.



STEP 2.




STEP 3.



Ratchet Back Height Adjustment
To raise the back, slowly lift the back up until you hear a series of 4 to 5 clicks. Each click represents a position where the back will lock into place. To lower the back, raise the back all the way up until tension is released - the back will then return to the lowest position without stopping. Raise back up to desired position.

If the up/down operation of the ratchet back feels tight, raise and lower the back several times after assembling the chair to insure smooth functioning.



MECHANISM INSTRUCTIONS:

- (A) Back angle adjustment lever.
- (B) Combination seat / back angle adjustment lever with infinite lock.
- (C) Seat height adjustment lever.
- (D) Forward tilt lever
- *While seated, lift lever B and then lean back to activate locking mechanism;
- *Pull lever D backward to allow seat to tilt forward - or - push lever D forward to straighten seat;
- *To lock in desired position, push lever B downward.
- (E) Tension control knob -Turn clockwise to increase tension and counter- clockwise to decrease tension.
- (F) Sliding seat:
Seat depth adjusts for different user leg lengths.

PREVENTIVE MAINTENANCE AND WARNING!

- USE THIS PRODUCT ONLY FOR SEATING ONE PERSON AT A TIME.
- DO NOT USE THIS CHAIR AS A STEP STOOL / LADDER.
- DO NOT SIT ON ANY PART OF THE CHAIR EXCEPT THE SEAT.
- DO NOT USE CHAIR ON UNEVEN FLOOR SURFACES.
- DO NOT USE CHAIR UNLESS ALL BOLTS, SCREWS AND KNOBS ARE TIGHTENED.
- EVERY SIX MONTHS, PLEASE MAKE SURE ALL BOLTS, SCREWS AND KNOBS ARE FULLY TIGHTENED TO ENSURE STABILITY.
- IF ANY PARTS ARE MISSING, BROKEN, DAMAGED OR WORN, STOP USE OF THE PRODUCT UNTIL REPAIRS ARE MADE USING FACTORY AUTHORIZED PARTS.
- DISPOSE OF PACKAGING PROPERLY. PLASTIC BAG IS NOT A TOY. DO NOT USE PLASTIC BAG AS HEAD COVERING - IT MAY CAUSE SUFFOCATION.
- FAILURE TO FOLLOW THESE WARNINGS COULD RESULT IN SERIOUS INJURY.
- NOTE: SOME SCREWS MAY BE PREASSEMBLED. IF PREASSEMBLED, IGNORE ASSEMBLY INSTRUCTIONS.