

# Security Cable


## ASSEMBLY INSTRUCTIONS




**LANCASTER™**  
TABLE & SEATING

### PARTS

**A** Security Cable (1)




**B** Cable Clips (2)



### TOOLS

**C** Heavy-Duty Pliers or Hand Crimping Tool  
(not included)




### STEP 1

Your security cable parts will be in their own bag. Before beginning, ensure you have 2 cable clips (B) and 1 security cable (A).


### STEP 2

Attach the security cable (A) to the cable lock bar on the inside top of your Lancaster Table & Seating trash can by sliding it through the hole. Once the cable is attached to the can, loop it through the cable lock bar of your Lancaster Table & Seating lid.



### STEP 3

Use the cable clips (B) to secure the cable tightly at the desired length. Using a hand crimping tool or heavy-duty pliers (C), crimp the cable clip(s) to ensure they stay in place.



Your lid and can should now be connected while still allowing for temporary lid removal to replace liners.

