



USER MANUAL




FLOOR FRYERS



Conforms to ANSI STD Z83.11b
Certified to CSA STD 1.8b
Conforms to NSF/ANSI STD 4

MODELS: 541FF40N, 541FF40L, 541FF50N, 541FF50L, 541FF100N, 541FF100L

FLOOR FRYERS





PARTS MANUAL

Key	Description	Part Number	QTY		
			541FF40	541FF50	541FF100
1	Housing	–	1	1	1
2	Fryer Pot Assembly	–	1	1	1
3	Chimney Assembly	–	1	1	1
4A	Chimney Cover for FF40 and FF50	541026061004	1	1	–
4B	Chimney Cover for FF100	541026065004	–	–	1
5A	Door For FF40 and FF50	541026061002	1	1	–
5B	Door for FF100	541026065002	–	–	1
6	Door Hinge	54126037002	1	1	1
7	Bottom Front Panel	–	1	1	1
8	Top Front Panel	–	1	1	1
9	Thermostat Bracket	–	1	1	1
10	Gas Pipe Mounting Bracket	–	1	1	1
11	Sensor Clamp	–	1	1	1
12	Pilot Bracket Connecting Plate	–	1	1	1
13	Adjustable Leg	541400000	4	4	4
14	Door Magnet	–	1	1	1
15	Drain Valve	541400036	1	1	1
16	Drain Extension	5412006273	1	1	1
17A	Pilot - Natural Gas	541400047N	1	1	1
17B	Pilot - Liquid Propane	541400047L	1	1	1
18	Safety Thermopile	541700237	1	1	1
19	Pilot Tube	541400070	1	1	1
20	High Limit Thermostat	541200737	1	1	1
21	Thermostat	541200728	1	1	1
22	Thermostat Knob	541103628	1	1	1
23	Burner	541300037	3	4	5
24	Gas Distribution Pipe Assembly	–	1	1	1
25	Manifold Adapter Assembly	–	1	1	1
26A	Combination Valve - Natural Gas	541500773	1	1	1
26B	Combination Valve - Liquid Propane	541500782	1	1	1
27	Straight Joint	–	1	1	1
28	Elbow	–	1	1	1
29	Manifold	–	1	1	1
30	Manifold Elbow	–	1	1	1
31	Manifold Bracket	–	2	2	2
32A	Crumb Screen for FF40	541400037	1	–	–
32B	Crumb Screen for FF50	54101102246	–	1	–
32C	Crumb Screen for FF100	541400058	–	–	1
33	Fryer Basket	–	2	2	2
34A	Orifice #39 - Natural Gas	541300034N	3	4	5
34B	Orifice #52 - Liquid Propane	541300035L	3	4	5