

# **Operating and Maintenance Instructions**

Model: 55650-PE 3/4" X 3/4" DICER 14 SECTION ONION TRI-CUT 5/16" ZUCCHINI SLICER

#### INTRODUCTION

- 1. To get the best operation and life from your machine, please read and comply with these instructions.
- 2. Clean machine thoroughly before and after each use using cleaning instructions below.
- 3. Minimize the use of alkaline cleaners as they may cause pitting and dulling of the finish.

#### SAFETY INSTRUCTIONS

Remember that the blades are <u>VERY SHARP</u>! Be careful when handling and operating the machine to keep hands away from the blades.

## **PPREPARATION**

- 1. The LEVER is locked in the down position (as it is shipped) for safety and convenience by inserting PIN through the HOLE in the LEVER.
- The LEVER can be locked in the up position to safely and conveniently remove the BLADE AND HOLDER ASSEMBLY by raising the LEVER so HOLE aligns with the holes in LINK BARS and inserting the PIN through all three parts.
- 3. Place the unit on a good firm work surface.
- 4. If unit fails to work properly when first operated call NEMCO customer service at 1-800-782-6761

#### **OPERATION**

- 1. Insert PIN into HOLE in LEVER.
- 2. Hold LEVER in its <u>UP</u> position and place the product on the BLADES.
- 3. Remove hand/fingers from the cutting area and firmly bring LEVER down, to cause the PUSH PLATE to force the product through the BLADES.

## **CLEANING**

- 1. Remove PIN, move LEVER out of the way and lift PUSH PLATE off the GUIDE RODS.
- 2. Release and raise HOLD DOWN CLIPS and lift the BLADE AND HOLDER ASSEMBLY off the FRAME.

  NOTE: The BLADE AND HOLDER ASSEMBLY can be totally disassembled for cleaning by removing the machine screws on the underside (see To Replace Blades for re-assembly instructions).
- 3. Reassemble by reversing the above procedure.

## TO LUBRICATE

If the PUSH PLATE doesn't slide freely, lubricate the GUIDE RODS with mineral oil or a food grade lubricant. Do not use cooking oil; it will get sticky!

#### TO REPLACE BLADES ON 55485-6, 34" x 34" DICER

- 1. Place BLADE AND HOLDER ASSEMBLY on a table with the sharp side of the BLADES down.
- 2. Remove the MACHINE SCREWS and the BLADE RETAINERS.
- 3. Remove the existing BLADES and install new with the sharp side down. Install the BLADES with the slots on the dull side first.
- 4. Reassemble the BLADE RETAINERS and the MACHINE SCREWS.

# TO REPLACE BLADES ON 56392, 14 SECTION TRI-CUT

- 1. Remove the screws from the bottom of the BLADE HOLDER. The BLADE ASSEMBLY can now be removed.
- 2. Install the new BLADE ASSEMBLY in THE BLADE HOLDER and fasten using screws provided with new BLADE ASSEMBLY.

7



