

### Decor Bug LED Light Trap/Bug Wall Sconce LED

#605WS16WDBKLED, #605WS16WDGDLED, #605WS16WDLEDLVR, #605WS16WDWHLED  
#605WSTM1BLE, #605WSTM1BAMLED, #605WSTM1SLED, #605WSTM1WLED,

Rated Voltage: 120V,  
Rated Frequency: 60HZ

**1 year**  
warranty

The insect killer uses the specified wavelength of a black light tube to attract insects. The insects are drawn towards a glue board and can't escape the strength of the glue. The glue board lasts between four and six weeks, depending on the situation, and is removed without the need for complicated tools. Users can simply switch off the unit and replace it.

The insect killer is highly efficient and completely harmless to humans and pets. The insect killer series are ideal for indoor use, such as houses, factories, restaurants and butcher shops, hospitals, etc.

### Warnings

- Read all the instructions before using the unit. Make sure that your local voltage and frequency is suitable for the unit. Ensure earthing connection to prevent damage or danger.
- The unit is to be kept out of reach of children. Hang or mount the unit in a place where children can't reach.
- The appliance is meant for indoor use only, do not use outdoors. The appliance is not suitable for use in barns, stables, and similar outdoor locations.
- To reduce the risk of electrical shock, do not put this product in water or other liquid. Do not place or store unit where it can fall into water.
- Always power off and disconnect the unit from the power supply before cleaning.
- Do not immerse the unit in water. Wipe the safety guard and external casing with a damp cloth.
- Replace the glue board regularly (once every month).
- Never remove any fixed part of the unit or make any internal adjustment to avoid electric shock. If the supply cord, lamp, starter, or other part of appliance is damaged, it must be replaced by the manufacturer, its service agent, or similarly qualified persons in order to avoid a hazard.
- Repair should be carried out by the manufacturer or qualified electricians.
- The appliance is not to be used in locations where flammable vapor or explosive dust is likely to exist.
- Delay time between disconnecting the appliance and cleaning the unit or replacing the bulb
- Do not spray with water or cleaning products. Liquid could contact the electrical components and cause a short circuit or an electrical shock. Do not use the unit if power cord is damaged or has been modified.
- The unit can be cleaned with a damp cloth.
- Unplug the unit before replacing the bulb. Carefully remove the old bulb, using caution as it may still be hot. Make sure the new bulb is properly installed in the unit and the cover is closed securely before plugging in and turning the unit back on.



**Environment-friendly disposal** You can help protect the environment! Please remember to respect the local regulations: hand in the non-working electrical equipment to an appropriate waste disposal center. The packaging material is recyclable. Dispose of the packaging in an environmentally friendly manner and make it available for the recyclable material collection service.