

Wooden Booster Seat


ASSEMBLY INSTRUCTIONS



LANCASTER
TABLE & SEATING

IMPORTANT: REFER TO SAFETY WARNINGS ON PAGE 3 BEFORE ASSEMBLY.

ASSEMBLED DIAGRAM:



HARDWARE:



(E)
Screws
8 Pcs



(F)
Allen Key
1 Pc

PARTS LIST:


(A) Side Panels	2
(B) Back Panel	1
(C) Seat Panel	1
(D) Horizontal Strut	1

NOTES:

1. Inspect all pieces for damage upon receipt and before assembly. Do not assemble or use if any pieces are broken or damaged.
2. DO NOT use a power drill during assembly.

STEP 1

Insert back B, C, and D into slot A. Ensure part C has the seat straps facing the bottom and on the back part of the booster seat. Straps are attached to the underside of the seat.



Wooden Booster Seat


ASSEMBLY INSTRUCTIONS



LANCASTER™
TABLE & SEATING


STEP 2

Starting with back B, install screws loosely in B, C, and D. Note: This item may need to be assembled on its side.




STEP 3

Place remaining side A on top of B, C, and D. Tap in place into wood slots. Note: This item may need to be assembled on its side.



STEP 4

Starting with back B, install screws loosely in B, C, and D.



Wooden Booster Seat


ASSEMBLY INSTRUCTIONS



LANCASTER
TABLE & SEATING

STEP 5

Tighten all screws, then stand upright.



CLEANING AND MAINTENANCE:

1. Periodically tighten screws as needed.
2. Wipe chair with slightly damp cloth.



⚠ WARNING ⚠

FALL HAZARD: Children have suffered severe head injuries including skull fractures when falling from booster seats. Falls can happen suddenly if child is not restrained properly.

- Only children capable of sitting upright, unassisted should use this booster seat.
- Ensure booster seat is strapped securely to the bottom of the chair and child is secured in booster seat with the restraint system.
- Stay near and watch child during use.
- Discontinue use of this booster seat if child is a maximum weight of 40lbs/18kgs.
- Never lift and carry child in booster seat.

80816765 / 80816766

Lancaster Table and Seating, 2205 Old Philadelphia Pike, Lancaster, PA 17602 • 1-800-942-0412



WARNING:

NEVER LEAVE CHILD UNATTENDED

ATTENTION:

NE JAMAIS LAISSER L'ENFANT
SANS SURVEILLANCE

ACHTUNG:

LASSEN SIE DAS KIND NICHT
UNBEAUF SICHTIGT

ADVERTENCIA:

NO DEJE AL NINO SIN VIGILANCIA