

# OWNER'S MANUAL FOR AUTO SERVE POPCORN STAND



Model/Number:
Auto Serve 8 Ounce Popcorn Machine Stand / #3070180

### www.ParagonConcessions.com

Paragon International, Inc • 731 W. 18<sup>th</sup> Street • P.O. Box 560 • Nevada, IA 50201 USA Phone (515) 382-8000 • Toll-free (800) 433-0333 • Fax (515) 382-8001 • Email: cs@manufacturedfun.com

A546 Rev. A

#### **Important Owner Information**

Record the model number, serial number and voltage in the spaces below (the data plate is located on the operator's side of the machine in the bottom right). Please have this information available when calling Paragon for service assistance.

Model No.		
Serial No.		

Business Hours: 8:00 AM to 4:30 PM Central Standard Time (CST)

Telephone: 515-382-8000; 800-433-0333

Email: at cs@manufacturedfun.com

Fax: 515-382-8001

Additional information can be found by visiting our web site at <a href="www.paragonconcessions.com">www.paragonconcessions.com</a>

#### INTRODUCTION

## PARAGON IS PROUD TO BE YOUR PARTNER FOR MANUFACTURED FUN.

Our goal is to provide you with the best solutions to attract customers, expand your business, and improve your profits. That's why this product has been specially-crafted to meet precise specifications for performance, efficiency, and output.



#### **Your Paragon Auto Serve 8 Ounce Stand features:**

- The Auto Serve Popcorn Stand was designed to seamlessly and stylistically fit the function of the Auto Serve 8 Ounce Popcorn Machine. Place the rubber feet and power cords of the Auto Serve Popcorn Machine (Models # 1108180 and 1108190, sold separately) and the Pro-Deluxe Butter Warmer (Model #2028B, sold separately) into the holes of the Auto Serve Stand and secure underneath the unit with the hardware provided.
- High quality stainless-steel, attractive finish.
- Sturdy construction that withstands heavy commercial use.
- Front and back lockable (keys and locks included) and convenient storage areas for quick storage and retrieval of supplies and access to the disposal bin.
- Incorporates a popcorn cup dispenser with a preinstalled gasket to fit the default size serving cup (cups sold separately, Paragon recommends 46-ounce popcorn cups, model numbers 1601, 1602, 1603).
- Master switch incorporated to the design of the stand providing a single switch box to plug in the Auto Serve Popcorn Machine (#1108180 and #1108190, sold separately) and the Pro-Deluxe Butter Warmer (#2028B, sold separately).
- Includes: a waste bin for popcorn spillage, serving drip pan to easily remove and clean butter spillage.





Front and back lockable (keys and locks included) and convenient storage areas for quick storage and retrieval of supplies and access to the disposal bin





Incorporates a popcorn cup dispenser with a preinstalled gasket to fit the default size serving cup (cups sold separately, Paragon recommends 46-ounce popcorn cups, model numbers 1601, 1602, 1603).





Master switch incorporated to the design of the stand providing a single switch box to plug in the Auto Serve Popcorn Machine (#1108180 and #1108190, sold separately) and the Pro-Deluxe Butter Warmer (#2028B, sold separately).





A waste bin for popcorn spillage, serving drip pan to easily remove and clean butter spillage.

Should you have any questions about your equipment, or would like to know more about our other innovative concession equipment and supplies, please contact us at 1-800-433-0333 or visit us on the web at: paragonconcessions.com

#### **UNPACKING**

Paragon carefully inspects each product during assembly and after completion to adhere to strict quality guidelines, and packs it securely to ensure safe delivery to each of our customers. Be sure to carefully remove all packing material and adhesive before any operation. Please examine your product to guarantee all equipment has arrived, complete and in good condition.

If you believe that any damage may have occurred during shipment or parts may be missing, please contact Paragon immediately for replacement.

#### **SAFETY PRECAUTIONS**

Paragon values your continued safety above all else. Please follow these guidelines when using your equipment to prevent injury and maximize product performance:



All equipment is designed and sold for commercial use only. Equipment is not to be used by the general public or intended for home use. No direct contact to equipment by the general public should be allowed when used in food service locations. Only trained personnel should operate this equipment.

Carefully read any and all instructions before beginning operation of the equipment.



Any alterations made to equipment by anyone other than certified Paragon personnel will void warranty and may also create unsafe working conditions. NEVER make alterations to the equipment.

Ensure equipment is secured to the stand to avoid tipping accidents.


#### **CONNECTING YOUR AUTO SERVE POPPER TO THE STAND**

The Auto Serve Popcorn Stand was designed to seamlessly and stylistically fit the function and fit of the Auto Serve 8 Ounce Popcorn Machine.

The Auto Serve Stand is delivered fully assembled. You will only need to connect the Auto Serve Popcorn Machine or Butter Warmer to the stand. To do so, we recommend having two people lift the popper on to the stand.


#### Connecting the popcorn machine to the stand:

- 1. Set the popcorn machine on the stand ensuring the holes on the bottom of the popper align with the holes on the top of the stand.
- 2. Fit the power cord of the popcorn machine into the hole in the stand and plug the popcorn machine into the outlet on the inside of the stand.
- 3. Once aligned, reach into the popcorn machine and place the cart screw (#25027, %-20x2) into each of the square holes at the four corners of the popcorn machine. Again, the screw should align and extend into the round holes of the stand. To complete the connection of the popper and stand, connect the four wing nuts (#20010 ½-20) and securely tighten.



#### Connecting the butter warmer (optional, sold separately) with stand:

- 1. Fit the butter warmer's power cord into the middle hole of the stand. Plug the butter warmer into the outlet on the inside of the stand.
- 2. Align the butter warmer's feet with the holes of the stand for a secure fit.



Paragon provides a metal plate to cover the holes in the stand when a butter warmer is not used. To use the metal plate, fit the rubber guides into the holes of the stand as shown in the diagram above.

Thank you for your purchase and enjoy!