










FLAT[®]

engineering stability

ASSEMBLY INSTRUCTIONS CANTILEVER BASE



Ensure instructions are followed during installation. Damages resulting from incorrect installation may result in voiding of warranty

10/230316 AI0010