

Assembly Instructions for The BOSS

(Start-Up Tips on opposite side)



1 Join Top Handle section to Tank.

Slide basket filter drain pipe into Tank through black gasket. It may be easier if you lay the Top Handle on its back. *Note: Be careful that the black gasket is not pushed into the Tank.*

2 connect quick-connect coupling to join pump supply pipe with Tank

3 insert 2 bolts (1 on each side of BOSS) to connect Top Handle section to Tank. Shown is the bolt on the left side. The other is on the right side. All Bolts, for steps 3 & 4, are in the bag labelled SS-BOSS-AssemblyBolts

4 insert 2 bolts on back to connect Top Handle section to Tank.



ENJOY your new BOSS !

Start-up Tips and Troubleshooting

➤ If the pump will not pump oil

- The first time you use The BOSS, there may be an air lock in the suction pipe from the tank to the pump. To free up this air lock:



- With the pump ON, ensure that the Wand nozzle is directing the oil into the fryer vat. While holding the blue handle on the top of The BOSS, rocking back and forth should free up the air lock and start the flow of oil.

➤ Helpful TIPS:

- If the Basket Filter plugs frequently and takes too long to drain, then you probably have very dirty oil and/or a lot of debris in your fryer vat. Before proceeding with the standard 1st step with the Basket Filter, use **The BOSS Basket Strainer** when flushing the fryer vat of debris. **The BOSS Basket Strainer** can be purchased from our website here: [Basket Strainer](#)
- When closing the Canister Filter within the Filter Housing, ensure that the Filter Housing gasket is seated evenly around the circumference to prevent leaks.