



**10.5" Round Gatsby™
Bento Box Set - Rose**
10.5 dia x 3.5 in | 26.8 dia x 8.9 cm
pack 6
DBE002PIT22



**10.5" Round Gatsby™
Bento Bowl - 120 oz - Rose**
10.5 dia x 2.75 in | 26.6 dia x 7.3 cm, 3.5 L
pack 6
DBO204PIT22



**10.5" Round Gatsby™
Serving Lid - Rose**
10.5 dia x 0.75 in | 26.8 dia x 1.9 cm
pack 6
DDP099PIT22



**7.5" Round Gatsby™
Bento Box Set - Rose**
7.5 dia x 3.5 in | 18.9 dia x 8.9 cm
pack 6
DBE001PIT22



**7.5" Round Gatsby™
Bento Bowl - 58 oz - Rose**
7.5 dia x 2.75 in | 18.8 dia x 7.3 cm, 1.7 L
pack 6
DBO203PIT22



**7.5" Round Gatsby™
Serving Lid - Rose**
7.5 dia x 0.75 in | 19 dia x 1.9 cm
pack 6
DAP094PIT22



**4.5" Round Gatsby™
Bento Bowl - 16 oz - Rose**
4.5 dia x 2.5 in | 11.4 dia x 6.3 cm, 473 ml
pack 6
DBO202PIT22



**4 oz Round Gatsby™
Bento Ramekin - Rose**
2.5 dia x 2 in | 6.4 dia x 4.8 cm, 118 ml
pack 6
ASC030PIT22