

**Coffee pot & lid**

Cafetière & couvercle
Kaffeekanne & Deckel
Cafetera & tapa
Caffettiera & coperchio

FDCP70 70 cl / 23.65 oz

FDCP35 35 cl / 11.85 oz

**Lid for coffee pot**

Couvercle pour cafetière
Deckel für Kaffeekanne
Tapa para cafetera
Coperchio per caffettiera

FDCPLD2 > FDCP70

FDCPLD1 > FDCP35

**Teapot & lid**

Théière & couvercle
Teekanne & Deckel
Tetera & tapa
Teiera & coperchio

FDTP80 80 cl / 27.05 oz

FDTP40 40 cl / 13.55 oz

**Lid for teapot**

Couvercle pour théière
Deckel für Teekanne
Tapa para tetera
Coperchio per teiera

FDTPLD2 > FDTP80

FDTPLD1 > FDTP40

**Creamer**

Crémier
Milchkännchen
Lechera
Bricco da latte

FDCR40 40 cl / 13.55 oz

FDCR25 25 cl / 8.45 oz

FDCR15 15 cl / 5.05 oz



FDCR05 5 cl / 1.70 oz

**Sugar bowl & lid**

Sucrier & couvercle
Zuckerdose & Deckel
Azucarero & tapa
Zuccheriera & coperchio

FDSU22 22 cl / 7.45 oz

**Lid for sugar bowl**

Couvercle pour sucrier
Deckel für Zuckerdose
Tapa para azucarero
Coperchio per zuccheriera

FDSULD

**Pepper shaker**

Poivrier
Pfefferstreuer
Pimentero
Pepiera

FDPS01

**Salt shaker**

Salière
Salzstreuer
Salero
Saliera

FDSS01



Pieces per box
Pièces par boîte
Stück pro Karton
Piezas por caja
Pezzi per scatola