ALL PURPOSE SHEARS Polypropylene Handle



● 87771 4" Kitchen Shear with Bottle Opener*

ALL PURPOSE SHEARS

KITCHEN SHEARS Polypropylene Handle



45903 4" Blade, Locking Handle, Hammered Textured 48884 Replacement Spring



◎ 87770 4" Kitchen Shear with Bottle Opener*



49898 3" Come-apart Kitchen Shear Rounded safety tip



87781 9" Paper Shear*



49896 3" Come-apart Kitchen Shear



40555 3" Stainless Steel Locking Blade* 48883 Replacement Spring



49899 Come-apart Poultry Shears 49899SP Replacement Spring



87777 6" Clip Point*



87779 8½" Bent Shear*