



Care and Cleaning of Polycarbonate Trays

Polycarbonate Items Include: Camwear® Trays, Camwear® Non-Skid Trays and Camwear® Compartment Trays

Below are detailed instructions on how to care for Cambro polycarbonate products.

1. All polycarbonate products need to be washed thoroughly before their initial use.
2. All polycarbonate items are commercial dishwasher safe:
 - Dishwasher Detergents
 - Suma Tempo L1.7
 - Control Plus
 - Suma Diverpak™ P6
 - Rinse Aids
 - Suma Klear A10
 - Suma Rinse A5
3. Occasionally, these products need to be washed by hand with:
 - Warm water and soap to prevent build-up. This would depend on the frequency with which the trays are used.
 - Use a Scotch-Brite™ pad or plastic or bristle brush when hand washing. (Scotch-Brite 2000 Power Pad, 5-1/2" Length x 3-7/8" Width, Dark Blue or Scotch-Brite 9030 Light Duty Scrubbing Pad, 5" Length x 3-1/2" Width, White)
 - Do **not** use abrasives (such as Comet, Ajax, etc., or metal scouring pads).
4. Rinse thoroughly with clean water.
5. Always make sure that the trays are dry before stacking.

The general rule with **STAINS** is the longer it's been there the harder it is to remove so regular light cleaning will quickly remove stains.

Note: for heavier/stubborn stains repeat steps 1 thru 4.

Disclaimer:

Please note that foods such as mustard, coffee, dark soft drinks, berries, fruit juice, green tea, tomato juice, tomato paste, curry and chili paste contain natural pigments that may stain trays if left on the surface for extended periods of time. To prevent staining, clean trays within one hour of use.