How To Use Chill-It® Pans and Pitchers

Care

Wash in hot water or in commercial dishwasher, using mild detergent.

Never place Chill-It® containers in ovens, on hot-plates, grills, griddles, range-top burners, or any heated surface.

Freezing and Use

Freeze Chill-It® containers, open-end down, at 0°F (-18°C) for eight hours or more

After appropriate freezing of a pan, crock or pitcher, fill with refrigerated product that is at or below 40°F(4°C)

Chill-It® containers will keep product at or below 40°F(4°C) for up to eight hours, beverages in pitchers up to 3 hours, under normal ambient temperatures. Warmer ambient temperatures may reduce cooling time.

After Use

Simply clean Chill-It® containers according to above directions, then re-freeze for eight hours before returning to service.

Precaution

Chill-It® containers feature gelatinous material that is sealed within double walls of strong, durable plastic. The freezable refrigerant material is non-toxic.



262-723-6133

800-248-9826

262-723-4204(fax)

Website: www.sanjamar.com

Orders: www.edispensers.com

Email: sanjamar@sanjamar.com