

820607 Compatibility Notes - 12/02/2016	
Model	Notes
TUC-48G	REQUIRES 874656 BRACKETS AND 874642 RIVNUT TOOL TO INSTALL. ORDER SEPARATELY.
TUC-48F	REQUIRES 874656 BRACKETS AND 874642 RIVNUT TOOL TO INSTALL. ORDER SEPARATELY.
TUC-48	REQUIRES 874656 BRACKETS AND 874642 RIVNUT TOOL TO INSTALL. ORDER SEPARATELY.
TUC-48F-D	REQUIRES 874656 BRACKETS AND 874642 RIVNUT TOOL TO INSTALL. ORDER SEPARATELY.
TUC-48D-4	REQUIRES 874656 BRACKETS AND 874642 RIVNUT TOOL TO INSTALL. ORDER SEPARATELY.
TUC-48-LP	REQUIRES 874656 BRACKETS AND 874642 RIVNUT TOOL TO INSTALL. ORDER SEPARATELY.
TUC-48G-LP	REQUIRES 874656 BRACKETS AND 874642 RIVNUT TOOL TO INSTALL. ORDER SEPARATELY.
TUC-48D-4-LP	REQUIRES 874656 BRACKETS AND 874642 RIVNUT TOOL TO INSTALL. ORDER SEPARATELY.
TUC-48F-LP	REQUIRES 874656 BRACKETS AND 874642 RIVNUT TOOL TO INSTALL. ORDER SEPARATELY.
TUC-48F-D-4	REQUIRES 874656 BRACKETS AND 874642 RIVNUT TOOL TO INSTALL. ORDER SEPARATELY.
TUC-48D-2	REQUIRES 874656 BRACKETS AND 874642 RIVNUT TOOL TO INSTALL. ORDER SEPARATELY.
TUC-48D-2-LP	REQUIRES 874656 BRACKETS AND 874642 RIVNUT TOOL TO INSTALL. ORDER SEPARATELY.
TUC-48-HC	REQUIRES 874656 BRACKETS AND 874642 RIVNUT TOOL TO INSTALL. ORDER SEPARATELY.
TUC-48F-HC	REQUIRES 874656 BRACKETS AND 874642 RIVNUT TOOL TO INSTALL. ORDER SEPARATELY.