

820635 Compatibility Notes - 12/02/2016	
Model	Notes
TUC-60G	REQUIRES 874656 BRACKETS AND 874642 RIVNUT TOOL TO INSTALL. ORDER SEPARATELY.
TUC-60D-2	REQUIRES 874656 BRACKETS AND 874642 RIVNUT TOOL TO INSTALL. ORDER SEPARATELY.
TUC-60F	REQUIRES 874656 BRACKETS AND 874642 RIVNUT TOOL TO INSTALL. ORDER SEPARATELY.
TUC-60D-4	REQUIRES 874656 BRACKETS AND 874642 RIVNUT TOOL TO INSTALL. ORDER SEPARATELY.
TUC-60	REQUIRES 874656 BRACKETS AND 874642 RIVNUT TOOL TO INSTALL. ORDER SEPARATELY.
TWT-60-32	REQUIRES 874656 BRACKETS AND 874642 RIVNUT TOOL TO INSTALL. ORDER SEPARATELY.
TWT-60-32D-2	REQUIRES 874656 BRACKETS AND 874642 RIVNUT TOOL TO INSTALL. ORDER SEPARATELY.
TUC-60-LP	REQUIRES 874656 BRACKETS AND 874642 RIVNUT TOOL TO INSTALL. ORDER SEPARATELY.
TUC-60G-LP	REQUIRES 874656 BRACKETS AND 874642 RIVNUT TOOL TO INSTALL. ORDER SEPARATELY.
TUC-60D-4-LP	REQUIRES 874656 BRACKETS AND 874642 RIVNUT TOOL TO INSTALL. ORDER SEPARATELY.
TWT-60-32F	REQUIRES 874656 BRACKETS AND 874642 RIVNUT TOOL TO INSTALL. ORDER SEPARATELY.
TUC-60F-LP	REQUIRES 874656 BRACKETS AND 874642 RIVNUT TOOL TO INSTALL. ORDER SEPARATELY.
TUC-60D-2-LP	REQUIRES 874656 BRACKETS AND 874642 RIVNUT TOOL TO INSTALL. ORDER SEPARATELY.
TWT-60-32HD	REQUIRES 874656 BRACKETS AND 874642 RIVNUT TOOL TO INSTALL. ORDER SEPARATELY.
TWT-60-32F-HD	REQUIRES 874656 BRACKETS AND 874642 RIVNUT TOOL TO INSTALL. ORDER SEPARATELY.
TUC-60G-FGD01	REQUIRES 874656 BRACKETS AND 874642 RIVNUT TOOL TO INSTALL. ORDER SEPARATELY.

TUC-60G-HC~FGD01	REQUIRES 874656 BRACKETS AND 874642 RIVNUT TOOL TO INSTALL. ORDER SEPARATELY.
TUC-60-HC	REQUIRES 874656 BRACKETS AND 874642 RIVNUT TOOL TO INSTALL. ORDER SEPARATELY.