

Model-Specific Compatibility Notes [06/09/2014]:

TWT-48: Used after 6/18/1990.

QA-60-24MB-L: N/A

TSSU-60-24M-DS: N/A

TSSU-48-12: Used after 6/18/1990.

TSSU-48-08: Used after 6/18/1990.

TSSU-48-8M: N/A

TSSU-72-30MB: Used after 6/18/1990 for left door. Use after 2/26/2007 for center door hinged left (pcn #3352).

TSSU-48-12M-B: N/A

TWT-72F: Used after 6/18/1990 for left door. Use after 2/26/2007 for center door hinged left (pcn #3352).

TSSU-60-12: Used after 6/18/1990.

TSSU-60-16D-2: N/A

QA-72-30MB: N/A

TSSU-36-12M-B: N/A

TSSU-27-08: Used after 6/18/1990.

TSSU-60-10: Used after 6/18/1990.

TUC-60D-2: Used after 6/18/1990.

TSSU-36-08: Used after 6/18/1990.

TSSU-27-12M: Used after 6/18/1990.

TUC-36: Used after 6/18/1990.

TSSU-60-24M-B: N/A

TSSU-60-24MB-DS: N/A

TUC-48F: Used after 6/18/1990.

TWT-36: Used after 6/18/1990.

TSSU-60-16: Used after 6/18/1990.

QA-48-18MB: N/A

TSSU-48-12M: Used after 6/18/1990.

TSSU-27-08F: N/A

TUC-27: N/A

TWT-27: Used after 6/18/1990.

TUC-72: Used after 6/18/1990 for left door. Use after 2/26/2007 for center door hinged left (pcn #3352).

TSSU-48-18M: Used after 6/18/1990.

TUC-36F: N/A

TSSU-48-10: Used after 6/18/1990.

TUC-48: Used after 6/18/1990.

TUC-60F: Used after 6/18/1990.

TSSU-48-15M-B: N/A

TUC-72F: Used after 6/18/1990 for left door. Use after 2/26/2007 for center door hinged left (pcn #3352).

TSSU-36-12M: Used after 6/18/1990.

TUC-GAL-48F: N/A

TSSU-72-30M: Used after 6/18/1990 for left door. Use after 2/26/2007 for center door hinged left (pcn #3352).

TUC-60: Used after 6/18/1990.

TWT-48F: Used after 6/18/1990.

TSSU-72-18D-2: Used after 6/18/1990 for left door. Use after 2/26/2007 for center door hinged left (pcn #3352).

TUC-27F: Used after 6/18/1990.

TWT-60: Used after 6/18/1990.

TSSU-27-12M-C: N/A

TSSU-60-21M: N/A

TSSU-60-14: N/A

TWT-60F: Used after 6/18/1990.

TSSU-72-30MB-DS: Used after 6/18/1990 for left door. Use after 2/26/2007 for center door hinged left (pcn #3352).

TSSU-60-16-DS: N/A

TSSU-48-18M-B: N/A

TWT-72: Used after 6/18/1990 for left door. Use after 2/26/2007 for center door hinged left (pcn #3352).

TSSU-60-08: Used after 6/18/1990.

TSSU-60-24M: Used after 6/18/1990.

TWT-27F: Used after 6/18/1990.

TSSU-72-18: Used after 6/18/1990 for left door. Use after 2/26/2007 for center door hinged left (pcn #3352).

TSSU-48-15M: Used after 6/18/1990.

TSSU-27-12M-B: N/A

TSSU-27-08-LP: N/A

TSSU-36-08-LP: N/A

TSSU-48-8-LP: N/A

TSSU-48-10-LP: N/A

TSSU-48-12-LP: N/A

TSSU-60-08-LP: N/A

TSSU-60-10-LP: N/A

TSSU-60-12-LP: N/A

TSSU-60-16-LP: N/A

TSSU-60-16-DS-LP: N/A

TSSU-27-12MB-LP: N/A

TSSU-27-12MC-LP: N/A

TSSU-36-12MB-LP: N/A

TSSU-48-12MB-LP: N/A

TSSU-48-15MB-LP: N/A

TSSU-48-18MB-LP: N/A

TSSU-60-24MB-LP: N/A

TSSU-60-24MB-DS-LP: N/A

TUC-27-LP: N/A

TUC-36-LP: N/A

TUC-48-LP: N/A

TUC-60-LP: N/A

TWT-27LP: N/A

TWT-36LP: N/A

TWT-48-LP: N/A

TWT-60LP: N/A

TUC-27F-LP: N/A

TSSU-72-10: Used after 6/18/1990 for left door. Use after 2/26/2007 for center door hinged left (pcn #3352).

TUC-48F-LP: N/A

TSSU-72-30M-B-ST: Used after 6/18/1990 for left door. Use after 2/26/2007 for center door hinged left (pcn #3352).

TSSU-60-24M-B-ST: N/A

TSSU-72-18-ST: Used after 6/18/1990 for left door. Use after 2/26/2007 for center door hinged left (pcn #3352).

TUC-60F-LP: N/A

TUC-48D-2: N/A

TUC-48D-2-LP: N/A

TWT-60D-2-LP: N/A

TWT-48D-2: N/A

TUC-60D-2-LP: N/A

TSSU-60-16-DS-ST: N/A

TSSU-60-24M-B-DS-ST: N/A

TSSU-72-30M-B-DS-ST: Used after 6/18/1990 for left door. Use after 2/26/2007 for center door hinged left (pcn #3352).

TSSU-48-12D-2: Used after 6/18/1990.

TSSU-72-30MB-ST-D2: Used after 6/18/1990 for left door. Use after 2/26/2007 for center door hinged left (pcn #3352).

TSSU-60-16-ST: N/A

TSSU-72-18M-B: Used after 6/18/1990 for left door. Use after 2/26/2007 for center door hinged left (pcn #3352).

TSSU-72-16: Used after 6/18/1990 for left door. Use after 2/26/2007 for center door hinged left (pcn #3352).

TSSU-72-12: Used after 6/18/1990 for left door. Use after 2/26/2007 for center door hinged left (pcn #3352).

TSSU-72-08: Used after 6/18/1990 for left door. Use after 2/26/2007 for center door hinged left (pcn #3352).

TSSU-60-12M-B: N/A

TSSU-72-24M-B-ST: Used after 6/18/1990 for left door. Use after 2/26/2007 for center door hinged left (pcn #3352).

TSSU-60-15M-B: N/A

TSSU-60-18M-B: N/A

TSSU-72-12M-B: Used after 6/18/1990 for left door. Use after 2/26/2007 for center door hinged left (pcn #3352).

TSSU-72-15M-B: Used after 6/18/1990 for left door. Use after 2/26/2007 for center door hinged left (pcn #3352).

TSSU-36-15MB: Used after 6/18/1990.

TSSU-72-12D-4: Used after 6/18/1990 for left door. Use after 2/26/2007 for center door hinged left (pcn #3352).

TSSU-72-18D-4: Used after 6/18/1990 for left door. Use after 2/26/2007 for center door hinged left (pcn #3352).

TSSU-72-30M-B-D-2: Used after 6/18/1990 for left door. Use after 2/26/2007 for center door hinged left (pcn #3352).

TUC-36-34: N/A

TSSU-48-18MB-D2: N/A

TSSU-60-08D-2: Used after 6/18/1990.

TSSU-72-40M-B-DS-ST: N/A

TSSU-72-16-ST: Used after 6/18/1990.

TUC-48WB-LP: N/A