

**Model-Specific Compatibility Notes [11/12/2014]:**

**TPP-93D-6:** Use with one piece-drain pan heater.

**T-49F:** Use with one piece-drain pan heater.

**TPP-93D-2:** Use with one piece-drain pan heater.

**T-49:** Use with one piece-drain pan heater.

**GEM-49:** Use with one piece-drain pan heater.

**TUC-67D-4:** Use with one piece-drain pan heater.

**T-49F-2-G-2:** Use with one piece-drain pan heater.

**TUC-GAL-93:** Use with one piece-drain pan heater.

**TS-72FG:** Use with one piece-drain pan heater.

**T-72-6:** Use with one piece-drain pan heater.

**TS-49G-4:** Use with one piece-drain pan heater.

**TSID-48-4:** Use with one piece-drain pan heater.

**TC-72G:** Use with one piece-drain pan heater.

**GDM-49DT:** Use with one piece-drain pan heater.

**T-49FZ:** Use with one piece-drain pan heater.

**GEM-69FC:** Use with one piece-drain pan heater. If used on cooler built after 11/17/98 or ser. no. 1-2228669, will need 875570 bar to support the drain pan.

**GDM-35:** Use with one piece-drain pan heater.

**T-72G-6:** Use with one piece-drain pan heater.

**GDM-69:** Use with one piece-drain pan heater. If used on cooler built after 11/17/98 or ser. no. 1-2228669, will need 875570 bar to support the drain pan. (standard on remote units).

**TSID-48-4-L:** Use with one piece-drain pan heater.

**TUC-67D-2:** Use with one piece-drain pan heater.

**TWT-67D-4:** Use with one piece-drain pan heater.

**TS-72-6:** Use with one piece-drain pan heater.

**TMC-49:** Use with one piece-drain pan heater.

**GDM-69FC:** Use with one piece-drain pan heater. If used on cooler built after 11/17/98 or ser. no. 1-2228669, will need 925066 bar to support the drain pan. (standard on remote units).

**TC-72:** Use with one piece-drain pan heater.

**TSID-72-2-L:** Use with one piece-drain pan heater.

**TPP-93D-4:** Use with one piece-drain pan heater.

**GDM-41:** Use with one piece-drain pan heater (standard on remote units).

**GDM-72:** Use with one piece-drain pan heater. If used on cooler built after 11/17/98 or ser. no. 1-2228669, will need 875570 bar to support the drain pan.

**GEM-49FC:** Use with one piece-drain pan heater.

**GDM-60:** Use with one piece-drain pan heater.

**T-72FG:** Use with one piece-drain pan heater.

**T-72F:** Use with one piece-drain pan heater (standard on remote units).

**GDM-35RF:** Use with one piece-drain pan heater.

**TSD-47G:** Use with one piece-drain pan heater. (standard on remote units).

**TS-49-1-G-3:** Use with one piece-drain pan heater.

**TPP-60D-2:** Use with one piece-drain pan heater.

**GEM-69:** Use with one piece-drain pan heater. If used on cooler built after 11/17/98 or ser. no. 1-2228669, will need 875570 bar to support the drain pan.

**TS-49G:** Use with one piece-drain pan heater. (standard on remote units).

**T-35:** Use with one piece-drain pan heater.

**TS-35:** Use with one piece-drain pan heater.

**TSID-72-4:** Use with one piece-drain pan heater.

**T-72FZ:** Use with one piece-drain pan heater.

**GDM-47RL:** Use with one piece-drain pan heater.

**TS-35F:** Use with one piece-drain pan heater.

**T-49FG:** Use with one piece-drain pan heater.

**TPP-119:** Use with one piece-drain pan heater.

**GEM-72:** Use with one piece-drain pan heater. If used on cooler built after 11/17/98 or ser. no. 1-2228669, will need 875570 bar to support the drain pan.

**T-49RL:** Use with one piece-drain pan heater.

**TUC-44:** Use with one piece-drain pan heater.

**TRCB-79:** Use with one piece-drain pan heater (standard on remote units).

**TWT-93D-6:** Use with one piece-drain pan heater.

**TWT-44D-2:** Use with one piece-drain pan heater.

**TS-49F-4:** Use with one piece-drain pan heater.

**T-35G:** Use with one piece-drain pan heater.

**TRCB-50:** Use with one piece-drain pan heater.

**TC-49:** Use with one piece-drain pan heater.

**GEM-72FC:** Use with one piece-drain pan heater. If used on cooler built after 11/17/98 or ser. no. 1-2228669, will need 875570 bar to support the drain pan.

**T-49F-4:** Use with one piece-drain pan heater.

**TS-49-2-G-2:** Use with one piece-drain pan heater.

**GDM-45HL:** Use with one piece-drain pan heater.

**TS-49F:** Use with one piece-drain pan heater.

**TSD-69:** Use with one piece-drain pan heater. Standard in remote compressor models.

**TSID-72-2:** Use with one piece-drain pan heater.

**TS-49-4:** Use with one piece-drain pan heater.

**TS-72:** Use with one piece-drain pan heater.

**GDM-69RL:** Use with one piece-drain pan heater. If used on cooler built after 11/17/98 or ser. no. 1-

2228669, will need 875570 bar to support the drain pan. (standard on remote units).

**T-49G-RL:** Use with one piece-drain pan heater.

**TS-72F:** Use with one piece-drain pan heater.

**TSID-96-6:** Use with one piece-drain pan heater.

**TS-35G:** Use with one piece-drain pan heater.

**TUC-93D-6:** Use with one piece-drain pan heater.

**TRCB-79-86:** Use with one piece-drain pan heater (standard on remote units).

**TMC-58:** Use with one piece-drain pan heater.

**GDM-47:** Use with one piece-drain pan heater (standard on remote units).

**T-49G-PT:** Use with one piece-drain pan heater.

**T-72G:** Use with one piece-drain pan heater.

**TSID-48-2:** Use with one piece-drain pan heater.

**TS-72-3-G-3:** Use with one piece-drain pan heater.

**TSD-47:** Use with one piece-drain pan heater.

**GDM-33C:** Use with one piece-drain pan heater.

**GDM-41C:** Use with one piece-drain pan heater.

**TWT-67D-2:** Use with one piece-drain pan heater.

**GDM-47FC:** Use with one piece-drain pan heater.

**GDM-37:** Use with one piece-drain pan heater.

**TSID-48-2-L:** Use with one piece-drain pan heater.

**TSD-69G:** Use with one piece-drain pan heater. Standard in remote compressor models.

**TUC-93:** Use with one piece-drain pan heater.

**T-49G:** Use with one piece-drain pan heater.

**TWT-44:** Use with one piece-drain pan heater.

**GDM-49RL:** Use with one piece-drain pan heater.

**TC-49G:** Use with one piece-drain pan heater.

**TSID-96-3:** Use with one piece-drain pan heater (standard on remote units).

**TS-49FG:** Use with one piece-drain pan heater.

**T-72F-6:** Use with one piece-drain pan heater.

**TWT-67:** Use with one piece-drain pan heater.

**TUC-67:** Use with one piece-drain pan heater.

**GDM-43F:** Use with one piece-drain pan heater (standard on remote units).

**T-72:** Use with one piece-drain pan heater.

**GDIM-49:** Use with one piece-drain pan heater.

**TPP-44D-2:** Use with one piece-drain pan heater.

**T-49-2-G-2:** Use with one piece-drain pan heater.

**GDIM-72NT:** Use with one piece-drain pan heater.

**TUC-60-32:** Use with one piece-drain pan heater.

**GDM-33:** Use with one piece-drain pan heater (standard on remote units).

**GDM-49:** Use with one piece-drain pan heater.

**GEM-47FC:** Use with one piece-drain pan heater.

**GDM-72FC:** Use with one piece-drain pan heater. If used on cooler built after 11/17/98 or ser. no. 1-2228669, will need 875570 bar to support the drain pan.

**GDM-49W-RF:** Use with one piece-drain pan heater.

**TUC-60-32D-2:** Use with one piece-drain pan heater.

**TS-49:** Use with one piece-drain pan heater.

**GDM-37HL:** Use with one piece-drain pan heater.

**GEM-47:** Use with one piece-drain pan heater.

**GDM-61:** Use with one piece-drain pan heater.

**TPP-67D-4:** Use with one piece-drain pan heater.

**GDM-49FC:** Use with one piece-drain pan heater.

**TWT-60-32:** Use with one piece-drain pan heater.

**GDM-69HL:** Use with one piece-drain pan heater (standard on remote units).

**GDIM-60:** Use with one piece-drain pan heater.

**TWT-93:** Use with one piece-drain pan heater.

**GDM-49RF:** Use with one piece-drain pan heater.

**TS-72G-6:** Use with one piece-drain pan heater.

**GDM-72RL:** Use with one piece-drain pan heater. If used on cooler built after 11/17/98 or ser. no. 1-2228669, will need 875570 bar to support the drain pan.

**T-72-3-G-3:** Use with one piece-drain pan heater.

**T-49DT:** Use with one piece-drain pan heater.

**T-35F:** Use with one piece-drain pan heater. Standard on remote units.

**T-35FZ:** Use with one piece-drain pan heater.

**T-49G-4:** Use with one piece-drain pan heater.

**TUC-44F:** Use with one piece-drain pan heater.

**T-35FG:** Use with one piece-drain pan heater.

**GDM-35F:** Use with one piece-drain pan heater (standard for remote units).

**GDIM-49NT:** Use with one piece-drain pan heater (standard on remote units).

**TSID-72-4-L:** Use with one piece-drain pan heater.

**GDM-61FC:** Use with one piece-drain pan heater.

**TRCB-110:** Use with one piece-drain pan heater.

**T-49-4:** Use with one piece-drain pan heater.

**TPP-60:** Use with one piece-drain pan heater.

**TPP-67:** Use with one piece-drain pan heater.

**TPP-93:** Use with one piece-drain pan heater.

**TPP-67D-2:** Use with one piece-drain pan heater.

**TPP-44:** Use with one piece-drain pan heater.

**GDM-49F:** Use with one piece-drain pan heater.

**GDM-72F:** Use with one piece-drain pan heater.

**GDM-57:** Use with one piece-drain pan heater.

**T-49PT:** Use with one piece-drain pan heater.

**TS-72G:** Use with one piece-drain pan heater.

**GDM-45:** Use with one piece-drain pan heater.

**TWT-60-32D-2:** Use with one piece-drain pan heater.

**TRCB-52:** Use with one piece-drain pan heater (standard on remote units).

**TPP-119D-8:** Use with one piece-drain pan heater.

**TUC-67F:** Use with one piece-drain pan heater.

**TUC-93F:** Use with one piece-drain pan heater.

**TCGG-72:** Use with one piece-drain pan heater.

**TWT-93F:** Use with one piece-drain pan heater.

**TUC-60-32F:** Use with one piece-drain pan heater.

**TWT-67F:** Use with one piece-drain pan heater.

**TWT-60-32F:** Use with one piece-drain pan heater.

**TUC-119:** Use with one piece-drain pan heater.

**TWT-119:** Use with one piece-drain pan heater.

**TWT-44F:** Use with one piece-drain pan heater.

**TPP-119D-2:** Use with one piece-drain pan heater.

**TPP-119D-4:** Use with one piece-drain pan heater.

**TPP-119D-6:** Use with one piece-drain pan heater.

**TUC-93D-4:** Use with one piece-drain pan heater.

**TUC-119D-4:** Use with one piece-drain pan heater.

**TUC-119D-6:** Use with one piece-drain pan heater.

**TUC-119D-2:** Use with one piece-drain pan heater.

**TUC-119D-8:** Use with one piece-drain pan heater.

**TWT-119D-2:** Use with one piece-drain pan heater.

**TWT-119D-4:** Use with one piece-drain pan heater.

**TWT-119D-6:** Use with one piece-drain pan heater.

**TWT-119D-8:** Use with one piece-drain pan heater.

**TUC-44D-2:** Use with one piece-drain pan heater.

**TUC-93D-2:** Use with one piece-drain pan heater.

**TWT-93D-2:** Use with one piece-drain pan heater.

**TWT-93D-4:** Use with one piece-drain pan heater.

**TSID-72-3-L:** Use with one piece-drain pan heater.

**TSID-72-6-L:** Use with one piece-drain pan heater.

**GEM-61FC:** Use with one piece-drain pan heater.

**TSID-72-3:** Use with one piece-drain pan heater.

**TSID-72-6:** Use with one piece-drain pan heater.

**TWT-67HD:** Use with one piece-drain pan heater.

**TUC-44HD:** Use with one piece-drain pan heater.

**TWT-44HD:** Use with one piece-drain pan heater.

**TUC-44F-HD:** Use with one piece-drain pan heater.



**TWT-44F-HD:** Use with one piece-drain pan heater.

**TUC-67HD:** Use with one piece-drain pan heater.

**TUC-67F-HD:** Use with one piece-drain pan heater.

**TWT-67F-HD:** Use with one piece-drain pan heater.

**TUC-93HD:** Use with one piece-drain pan heater.

**TUC-93F-HD:** Use with one piece-drain pan heater.

**TWT-93HD:** Use with one piece-drain pan heater.

**TWT-93F-HD:** Use with one piece-drain pan heater.

**TUC-60-32HD:** Use with one piece-drain pan heater.

**TWT-60-32HD:** Use with one piece-drain pan heater.

**TUC-60-32F-HD:** Use with one piece-drain pan heater.

**TWT-60-32F-HD:** Use with one piece-drain pan heater.

**TCGR-59:** Use with one piece-drain pan heater.

**TRCB-52-60:** Use with one piece-drain pan heater (standard on remote units).

**TRCB-96:** Use with one piece-drain pan heater.

**GDM-49F FAMILY DOLLAR:** Use with one piece-drain pan heater.

**GDM-72 FAMILY DOLLAR:** Use with one piece-drain pan heater. If used on cooler built after 11/17/98 or ser. no. 1-2228669, will need 875570 bar to support the drain pan.

**GDM-49 DOLLAR GENERAL:** Use with one piece-drain pan heater.

**GDM-49F DOLLAR GENERAL:** Use with one piece-drain pan heater.

**GEM-49 SUBWAY:** Use with one piece-drain pan heater.

**GDM-72 DOLLAR GENERAL:** Use with one piece-drain pan heater. If used on cooler built after 11/17/98 or ser. no. 1-2228669, will need 875570 bar to support the drain pan.

**GDM-72F DOLLAR GENERAL:** Use with one piece-drain pan heater.

**TCGG-60:** Use with one piece-drain pan heater (standard on remote units).

**T-49-4PT:** Use with one piece-drain pan heater.

**GDM-72F FAMILY DOLLAR:** Use with one piece-drain pan heater.

**TRCB-72:** Use with one piece-drain pan heater (standard on remote units).

**T-49MHC:** Use with one piece-drain pan heater.

**T-43:** Use with one piece-drain pan heater.

**TS-43:** Use with one piece-drain pan heater.