Model-Specific Compatibility Notes [12/15/2014]:

TWT-48: Option. Used after \sim 10/12/2009 when lock is requested (pcn #4243) lock is located in the countertop (requires 1 per door).

TUC-60G: Option. Used after \sim 10/12/2009 when lock is requested (pcn #4243) lock is located in the countertop (requires 1 per door).

TUC-48G: Option. Used after \sim 10/12/2009 when lock is requested (pcn #4243) lock is located in the countertop (requires 1 per door).

TUC-27FG: Option. Used after \sim 10/12/2009 when lock is requested (pcn #4243) lock is located in the countertop (requires 1 per door).

TUC-36: Option. Used after \sim 10/12/2009 when lock is requested (pcn #4243) lock is located in the countertop (requires 1 per door).

TWT-48G: Option. Used after \sim 10/12/2009 when lock is requested (pcn #4243) lock is located in the countertop (requires 1 per door).

TUC-48F: Option. Used after \sim 10/12/2009 when lock is requested (pcn #4243) lock is located in the countertop (requires 1 per door).

TWT-36: Option. Used after \sim 10/12/2009 when lock is requested (pcn #4243) lock is located in the countertop (requires 1 per door).

TUC-27: Option. Used after \sim 10/12/2009 when lock is requested (pcn #4243) lock is located in the countertop (requires 1 per door).

TWT-27: Option. Used after \sim 10/12/2009 when lock is requested (pcn #4243) lock is located in the countertop (requires 1 per door).

TUC-72: Option. Used after \sim 10/12/2009 when lock is requested (pcn #4243) lock is located in the countertop (requires 1 per door).

TUC-27G: Option. Used after \sim 10/12/2009 when lock is requested (pcn #4243) lock is located in the countertop (requires 1 per door).

TUC-48: Option. Used after \sim 10/12/2009 when lock is requested (pcn #4243) lock is located in the countertop (requires 1 per door).

TUC-60F: Option. Used after \sim 10/12/2009 when lock is requested (pcn #4243) lock is located in the countertop (requires 1 per door).

TUC-60: Option. Used after \sim 10/12/2009 when lock is requested (pcn #4243) lock is located in the countertop (requires 1 per door).

TUC-27F: Option. Used after ~10/12/2009 when lock is requested (pcn #4243) lock is located in the

countertop (requires 1 per door).

TWT-60: Option. Used after \sim 10/12/2009 when lock is requested (pcn #4243) lock is located in the countertop (requires 1 per door).

TWT-60F: Option. Used after \sim 10/12/2009 when lock is requested (pcn #4243) lock is located in the countertop (requires 1 per door).

TWT-72: Option. Used after \sim 10/12/2009 when lock is requested (pcn #4243) lock is located in the countertop (requires 1 per door).

TWT-60G: Option. Used after \sim 10/12/2009 when lock is requested (pcn #4243) lock is located in the countertop (requires 1 per door).

TWT-27F: Option. Used after \sim 10/12/2009 when lock is requested (pcn #4243) lock is located in the countertop (requires 1 per door).

TWT-60-32D-2: Option. Used after \sim 10/12/2009 when lock is requested (pcn #4243) lock is located in the countertop (requires 1 per door).

TUC-27-LP: Option. Used after \sim 10/12/2009 when lock is requested (pcn #4243) lock is located in the countertop (requires 1 per door).

TUC-36-LP: Option. Used after \sim 10/12/2009 when lock is requested (pcn #4243) lock is located in the countertop (requires 1 per door).

TUC-48-LP: Option. Used after \sim 10/12/2009 when lock is requested (pcn #4243) lock is located in the countertop (requires 1 per door).

TUC-60-LP: Option. Used after \sim 10/12/2009 when lock is requested (pcn #4243) lock is located in the countertop (requires 1 per door).

TUC-27G-LP: Option. Used after ~10/12/2009 when lock is requested (pcn #4243) lock is located in the countertop (requires 1 per door).

TUC-48G-LP: Option. Used after \sim 10/12/2009 when lock is requested (pcn #4243) lock is located in the countertop (requires 1 per door).

TUC-60G-LP: Option. Used after ~10/12/2009 when lock is requested (pcn #4243) lock is located in the countertop (requires 1 per door).

TWT-36LP: Option. Used after \sim 10/12/2009 when lock is requested (pcn #4243) lock is located in the countertop (requires 1 per door).

TWT-48-LP: Option. Used after \sim 10/12/2009 when lock is requested (pcn #4243) lock is located in the countertop (requires 1 per door).

TWT-60LP: Option. Used after ~10/12/2009 when lock is requested (pcn #4243) lock is located in the

countertop (requires 1 per door).

TUC-27F-LP: Option. Used after \sim 10/12/2009 when lock is requested (pcn #4243) lock is located in the countertop (requires 1 per door).

TUC-60F-LP: Option. Used after \sim 10/12/2009 when lock is requested (pcn #4243) lock is located in the countertop (requires 1 per door).

TUC-60G~FGD01: Lock is located in the countertop (requires 1 per door).