Model	Notes
DSF78	For use on ETL certified units. Units without ETL certification should use 348PDSFFOOT.
DSF94	For use on ETL certified units. Units without ETL certification should use 348PDSFFOOT.