

TIPS TO CHOOSE THE CORRECT REPLACEMENT PUMP

MATCH ENGINE ORIENTATION



Horizontal Engine

Pump is mounted horizontally off of the engine

Vertical Engine

Pump is mounted vertically below the engine

MATCH PSI AND GPM



Match your machine's ratings, often found on the dashboard of your machine or find it on the serial plate

* Engine power and pump performance are matched for optimal machine performance

MATCH THE ENGINE SHAFT DIAMETER



Most vertical pumps have a 7/8" shaft diameter
Most horizontal pumps have a 3/4" shaft diameter or 1" shaft diameter

* Check your engine to confirm specifications

MATCH CURRENT PUMP OUTLET CONNECTION



Match the outlet connection to your current pump

This will ensure that your accessories will work with your new pump

* Adapters may be needed if connections do not match