




CORE TORCH



CALL
800.500.0583

EMAIL
support@whipit.com

www.whipit.com



1

Attach The Torch

In a hazard-free environment, verify that the **Flame Adjuster** is OFF by turning the **Flame Adjuster Dial** to the right until it is locked. DO NOT FORCE. Attach the blowtorch to the gas cylinder on a leveled surface by firmly rotating the cylinder left until the **Gas Valve** is affixed securely. For hands-free use, attach the base stand to the bottom of the gas cylinder.

2

Ignition and Flame Adjustment

Turn the **Flame Adjuster** slowly to the left until it makes a slight HISSING sound, then press the **Ignition Button** and gradually turn left to increase (+) or right (-) to decrease the flame size. Rotate the **Flame Adjuster** all the way to the right to shut off.

3

Safety and Storage

Make sure the blowtorch has cooled before storing. To remove the blowtorch from the gas cylinder, rotate the cylinder right until the **Gas Valve** detaches. Store separately at room temperature below 40°C / 104°F and away from children at all times. Never store the blowtorch with the gas cylinder attached.

Scan for
Product
Details:



! WARNING

Do not touch the flame guard while in use or until sufficient time has passed for cooling. Do not immerse this product or heated parts in water. Allow to cool naturally. For best results, always use **Whip-It! Butane Gas** in the torch. Do not use propane gas or any other types of fluids. Do not store in a temperature exceeding 40°C / 104°F. Keep away from eyes at all times. The torch flame is nearly invisible in bright light or sunlight. Make sure that gas flow is turned off when not in use. Do not pack this item in any checked or carry-on baggage. This product is flammable. Keep away from fire, open flames and hot surfaces. Failure to comply with these warnings may result in bodily harm or other accidents. Keep this unit out of reach of children at ALL times.

WARRANTY

Whip-It! firmly believes in delivering high-quality products. We offer a **Limited Lifetime Warranty** on all mechanical parts and labor with the ordinary use of your torch. This warranty excludes coverage for damages resulting from misuse, tampering and abuse. For more information, please visit our website or contact us directly.