

Machine Control Panel
B:BLACK
Br:BROWN
G:GREEN
Gy:GRAY
L:BLUE
O:ORANGE
R:RED
W:WHITE
Y:YELLOW
P:PINK
B/W:BLACK/WHITE
G/Y:GREEN/YELLOW
R/W:RED/WHITE
AC coil
Sub coil
Main coil
Main coil
Sub coil
FU 5A
Ciruit breaker 20A
Ciruit breaker 20A
Parallel soket
Main Ciruit breaker 2P-28A
Inverter module
Stepping motor
Stepping motor
Fuel position sensor
Temperature sensor
Carbon monoxide module
Battery switch
OFF
ON
IG
E
BAT
Key
FS
FU 10A
Charger port
Low oil sensor
Sparking plug
Ignition coil
Trigger
Gasoline solenoid valve
SCM
Start relay
Battery
Start motor