

MOTOR
AC coil
Sub coil
Main coil
Main coil
Sub coil
Stepping motor
Stepping motor
Temperature sensor
Carbon monoxide module
CO alert
Inverter module
Voltage Regulator 600W/58.8V
Main Ciruit breaker 2P-44A
Ciruit breaker 20A
Ciruit breaker 2P-30A
Parallel socket
Line-2
Line-1
DC+
DC-
Low idle switch
Display
Machine Control Panel
B:BLACK
Br:BROWN
G:GREEN
Gy:GRAY
L:BLUE
O:ORANGE
R:RED
W:WHITE
Y:YELLOW
P:PINK
B/W:BLACK/WHITE
G/Y:GREEN/YELLOW
R/W:RED/WHITE
FU15A
Charger port
Battery switch
OFF
ON
Start relay
Battery
Start motor
LPG solenoid valve
Gasoline solenoid valve
Low oil sensor
Sparking plug
Ignition coil
Trigger
ENGINE