





KitchenAid®

ORION COMMERCIAL BLENDER

MODELS:

KSBC1B0CU0 (Contour Silver)
KSBC1B0BM0 (Black Matte)

JAR ASSEMBLY PARTS




JAR ASSEMBLY PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10703914	Ingredient Cup Assembly
2	W10703913	Lid, Jar
3	W10852144	Jar Assembly

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
4	W10703963	Pad, Jar
5	W10732363	Jar
6	W10732357	Bearing
7	W10732358	O-Ring

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
8	W10703968	Nut, Jar
9	W10793007	Blade
10	W10842608	Acorn Nut

UNIT PARTS



UNIT PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Literature Parts	10	W10762751	Electronic Control	21		Upper Base
	W10851732	Use & Care Guide	11	W10827118	Power Cord		W10854255	Contour Silver
2	W10762747	Trimband	12	W10797339	Tamper		W10732367	Black Matte
3	W10884366	Rotary Switch	13	W10703959	Coupler	22		Lower Base
4	W10762757	Bezel, Rotary Switch	14	W10908337	Screw		W10854256	Contour Silver
5	W10790752	Screw	15	W10811507	Base		W10878487	Black Matte
6	W10762759	Knob, Rotary Switch	16	W10802704	Seal, Motor			
7	W10732369	Toggle LED Lens	17	W10645565	Motor			
8	W10703983	Toggle Switch Assembly	18	W10584177	Screw			
9	W10790765	Screw	19	3400814	Screw			
			20	3400617	Screw			