



Pegasus 500H

Part List

Item No.	Part No.	QTY	Description	Item No.	Part No.	QTY	Description
1	41-00620	1	Hose, Drain, With Cap	24	39-00004	3	Latch
2	41-00017	1	Hook & Loop Strap, Wand Holder	25	41-00001	1	Pressure Gauge 1000 PSI
3	39-00017	2	Wheel, 3"	26	40-00806	1	Grounding Bar
4	41-09507	2	Ball Float	27	50-00002	1	Pressure Regulator/Unloader
5	01-10781-001	1	Recovery Tank Inlet Cover	28	41-00007	1	Quick Disconnect, Male
6	01-10765-001	1	Recovery Tank, Pegasus 500	29	31-00002	2	Washer, High Temperature
7	41-00050	1	Hose Barb, for 1-½" Hose	30	39-00019	2	Caster
8	01-10766-001	1	Solution Tank, Pegasus 500	31	40-00007	2	Power Cord, 25 ft
9	41-00011	1	Hose Barb/Elbow, 90°	31A	40-00008	2	Power Cord, Pigtail
10	52-00004	1	Lid, Solution Tank	32	52-00006	2	Wheel, 12"
11	40-00400	4	Switch, Vacs, Pump & Heat	33	41-00060	1	Axle
12	42-00042	1	Switch Plate	34	32-00002	2	Axle Cap
13	41-00069	1	Filter, Pump Inlet	35	42-00031	1	Heater, Complete
14	41-00512	1	Hose, ½" ID X 23.5", Pump Inlet Hose	36	05-30004	1	Repair Kit, Heater
15	50-00003	1	Pump & Motor, 500 PSI, w/bearing	37	41-00616	2	Check Valve Vacuum
16	35-00036	1	Muffler Vacuum Motor	38	41-00521	1	Hose, Heater to Outlet QD
17	41-00524	1	Hose, Pump to Unloader	39	41-00523	1	Hose, Unloader to Heater
18	41-00524	1	Hose, Pump to Pressure Gauge, 17"	40	01-10767-01	1	Base Compartment, Pegasus 500
19	41-00022	1	Quick Disconnect, Female	41	41-00512	1	Hose, ½" X 25", From Unloader to Tank
20	52-00010	2	Vacuum Motor, 3-stage	42	39-00210	1	Check Valve Cover
21	41-01303	2	Gasket, Vacuum, 5" OD	43	401-00619	1	Water Diffuser
22	39-00161	9	Vent Extractor Base	44	39-00003	3	Strike, For Latch
23	50-00153	1	Dual Cord Indicator light	45	01-10768-001	1	Vacuum Motor Cover