



Spare Parts DIAGRAM

KF-I 50PS



KF-I 50CST



No.	Description	No.	Description
1	AC Cord	13	Upper Cover
2	Power Switch	14	Washer
	Temperature Controller	15	Silicone Rubber
3	Protected Spring	16	Clamp
4	Down Cover	17	Support Hook
5	Reverted Spring	18	Iron Chain
6	Fixed Screw	19	S Connector
7	Side Fixed Plate	20	Foot Pedal
8	Top/Bottom Sealing Jaw	21	*Rubber Foot (not shown)
9	Heating Element	24	Pin for Teflon Cloth
10	Heat Element Fixed Plate	25	Teflon Cloth
11	Insulated Washer	26	Silicone Rubber Holder
12	Fixed Bolt		*Clamp & Pedal Set #16-21