

Faucet Timing Adjustment Guide




WATERLOO


This faucet comes standard with a pre-set water run time, but is easily adjustable. Just follow this step-by-step installation guide.

1. Turn left to shorten the amount of time the valve stay open or right to lengthen the amount of time.
2. Once you have achieved the desired run time, place the cap back on the stem. Tighten the set screw to hold the cap in place, then replace the red or blue temperature indicator button.


(Preset timing for Waterloo metering faucets is 8 seconds.)



Top View



Turn right to lengthen the amount of time



Turn left to shorten amount of time